



XDrum Drum Stool Semi

ArtNo. : 00006432



Assembly instructions

Version: 05.2021

© 2021

These operating instructions are protected by copyright. Reproduction of these operating instructions, even in part, is only permitted with the permission of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, even in modified form.

Detailed safety instructions:

- Read these instructions.
- Keep these instructions in a safe place.
- Heed all warnings. Follow all instructions.
- Clean the unit only with a dry cloth.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Contact qualified service personnel for all repair/maintenance work.

Thank you for choosing this product.

To ensure that you are fully satisfied with this drum stool, please read carefully and understand these assembly instructions before using our product. Keep these assembly instructions in a safe place. The assembly instructions must be passed on to all subsequent users.



Follow the operating instructions!



The signal word WARNING indicates hazards that can lead to serious injuries if no precautionary measures are taken.



The signal word NOTE indicates general precautions that should be observed when handling the product.



Images and screen representations in these assembly instructions may differ slightly from the appearance of the actual product, as long as this does not have a negative impact on the technical properties and safety of the product.



All person-related formulations in these assembly instructions are to be regarded as gender-neutral.

These assembly instructions apply to persons who have been supervised or instructed in the operation of the product by a person responsible for their safety and who have demonstrated their ability to handle the product.



**Children should be supervised to ensure that they do not play with the product.
Do not leave children unattended.**

All information in these assembly instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damage in connection with the use of these assembly instructions.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.

Assembly of your XDrum drum stool:



(Fig.1)

Unfold the tripod and secure it for a firm stand with the lower wing screw. (Fig. 1)



(Fig. 2)

Insert the rod, which you will later use for height adjustment, into the three-legged stand and now use the wing screw to fix the desired seat height of the stool. (Fig.2)



(Fig. 3)

Finally, you can attach the seat to the top of the bar and fix it with a wing screw. The seat position is now height-adjustable from 50 cm to 62 cm. (Fig. 3)

**WEEE Declaration
(Waste of Electrical and Electronic Equipment)**

Your product has been designed and manufactured using high quality materials and components that are recyclable and reusable. The symbol means that your product must be disposed of separately from household waste at the end of its life.

Dispose of this appliance at your local collection point or recycling centre.

Please help protect the environment in which we all live.

All technical data and appearances are subject to change without notice. All information was correct at the time of going to press. Musikhaus Kirstein GmbH does not guarantee the accuracy or completeness of the descriptions, photographs or statements contained in this manual. Printed colours and specifications may differ slightly from the product. Musikhaus Kirstein GmbH products are only sold through authorised distributors. Distributors and dealers are not representatives of Musikhaus Kirstein GmbH and are not authorised to legally bind Musikhaus Kirstein GmbH in any way.



Kirstein Music House GmbH

Bernbeurener Str. 11

86956 Schongau - Germany

Phone: 0049-8861-909494-0

Fax / Fax: 0049-8861-909494-19



Classic Cantabile AP-30 Active Monitor

ArtNo. : 00011178



Operating instructions

Version: 02.2021

© 2021

These operating instructions are protected by copyright. Reproduction of these operating instructions, even in part, is only permitted with the permission of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, even in modified form.

Content

Detailed safety instructions:	2
Using the Active Monitor	3
Controls:	4
Connections:	5
WEEE Declaration (Waste of Electrical and Electronic Equipment)	6

Thank you for purchasing this Classic Cantabile Active Monitor.
To ensure that you are completely satisfied with the item, please read carefully and understand this owner's manual before using our product. Keep these operating instructions in a safe place. The operating instructions must be passed on to all subsequent users.



Follow the operating instructions!



WARNUNG

The signal word **WARNING** indicates hazards that can lead to serious injuries if no precautionary measures are taken.



HINWEIS

The signal word **NOTE** indicates general precautions to be observed when handling the product.



HINWEIS

Images and screen representations in these operating instructions may differ slightly from the appearance of the actual product, as long as this does not have a negative impact on the technical characteristics and safety of the product.



HINWEIS

All person-related formulations in these operating instructions are to be regarded as gender-neutral.

These operating instructions apply to persons who have been supervised or instructed in the operation of the appliance by a person responsible for their safety and who have demonstrated their ability to handle the appliance.



WARNUNG

**Children should be supervised to ensure that they do not play with the appliance.
Do not leave children unattended.**

All information in these operating instructions has been checked to the best of our knowledge and belief. However, neither the author nor the publisher can be held liable for any damage in connection with the use of these operating instructions.

Other product, brand and company names mentioned in this document may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.

Detailed safety instructions:

- Read these instructions.
- Keep these instructions in a safe place.
- Heed all warnings. Follow all instructions.
- Do not use this appliance near water.
- Clean the unit only with a dry cloth.
- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not step on the cable and avoid pinching it, especially at the cable plug, the socket and the cable exit from the appliance.
- Use only stands, tripods, brackets or tables specified by the manufacturer or sold with the unit. Handle with care to avoid injury.
- Pay attention to the volume! Listening at too high a volume level can permanently damage your hearing.
- Disconnect this unit from the power supply during thunderstorms or when not in use for long periods of time.
- Contact qualified service personnel for all repair/maintenance work. Do not open the unit or the housing without authorisation. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Specifications:

Power supply: AC 120V~, 60 Hz

Power: 40W

Weight: 15kg

Dimensions: 351x345x367mm

Use of the Active Monitor

Installation place

Do not expose your device to the following conditions to avoid deformation, discolouration or more serious damage:

- Direct sunlight
- Too high temperatures (near a heat source or in a car exposed to direct sunlight).
- Humidity

Operation and transport

Do not apply excessive force to the rotary joints, connections or other parts of the box for use.

Always pull the cables out of the socket by the plug and not by pulling on the cable. Disconnect the cables from all sockets before moving the product.

Dropping the unit, bumping it or placing heavy objects on it may result in damage to the unit. In this case, scratches or other more serious damage may also occur.

Electronic noise

This product contains digital circuitry and may occasionally interfere with radio or television equipment if placed too close to it. If such interference occurs, move the speaker further away from the affected equipment.

Cleaning

Clean the instrument with a dry, lint-free cloth. A slightly damp cloth can remove stubborn dirt from the instrument.

Do not use chemical cleaning agents containing alcohol or thinner.

Do not place vinyl objects on the unit.

Switch off the unit before connecting it to the power supply


To avoid damage to your unit and connected instruments, switch off all connected equipment before connecting or disconnecting power.

Energy supply

Switch the "Power" button to "OFF" when you are not using the unit.


Controls:

Front



1. "Power" button - Switch the unit on or off
2. "Treble" knob - Allows you to adjust the treble in the mix
3. "Middle" knob - Regulate the mids in the mix
4. "Bass" knob - This can be used to raise or lower the bass in the mix
5. AUX Volume Knob - Use this knob to adjust the output volume of the external audio signal.
6. "Drum Volume" knob - Use this knob to regulate the output volume of the connected instrument.
7. AUX IN socket - input socket for connecting external audio equipment
8. Drum IN socket (left and right) - input socket for digital instruments such as e-drums

Back cover



If the power supply does not match the requirements of the amplifier, the electrical fuse may be damaged.


If the amplifier does not operate normally, have this fuse checked.

Connections:

Connecting the power cable




Make sure that the amplifier is switched off while connecting or disconnecting the unit from the power source.



Connect the power cable to the power input socket on the back of the box.

Plug the power cable into the socket.


Connecting the Drum IN socket



Connect your digital drum set via audio cable to the Drum IN socket of the amplifier while it is switched off.

The volume of the digital drum set can be changed by the "Drum Volume" control.

AUX IN socket



Connect your external audio device (e.g. MP3 player, mobile phone, etc.) to the AUX IN socket to play your favourite songs parallel to the drum kit sound.

The volume of the external audio device can be changed using the AUX volume control.

WEEE Declaration (Waste of Electrical and Electronic Equipment)

Your product has been designed and manufactured using high quality materials and components that are recyclable and reusable. The symbol means that your product must be disposed of separately from household waste at the end of its life. Dispose of this appliance at your local collection point or recycling centre. Please help protect the environment in which we all live.

All technical data and appearances are subject to change without notice. All information was correct at the time of going to press. Musikhaus Kirstein GmbH does not guarantee the accuracy or completeness of the descriptions, photographs or statements contained in this manual. Printed colours and specifications may differ slightly from the product. Musikhaus Kirstein GmbH products are only sold through authorised distributors. Distributors and dealers are not representatives of Musikhaus Kirstein GmbH and are not authorised to legally bind Musikhaus Kirstein GmbH in any way.


KIRSTEIN.de

Musikhaus Kirstein GmbH
Bernbeurener Str. 11
86956 Schongau - Germany
Phone: 0049-8861-909494-0
Fax / Fax: 0049-8861-909494-19



DIGITAL DRUM

Owner's Manual



INFORMATION FOR YOUR SAFETY!

THE FCC REGULATION WARNING (for USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modifications to this system may void the user's authority to operate this equipment.

CAUTION

The normal function of the product may be disturbed by strong electromagnetic interference. If so, simply reset the product to resume normal operation by following the owner's manual. If the function cannot be resumed, please use the product in another location.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.

Power Supply

Please connect the designated AC adapter to an AC outlet of the correct voltage.

Do not connect it to an AC outlet of voltage other than that for which your instrument is intended.

Unplug the AC power adapter when not using the instrument, or during electrical storms.

Connections

Before connecting the instrument to other devices, turn off the power to all units. This will help prevent malfunction and / or damage to other devices.

Location

Do not expose the instrument to the following conditions to avoid deformation, discoloration, or more serious damage:

- Direct sunlight
- Extreme temperature or humidity
- Excessively dusty or dirty locations
- Strong vibrations or shocks
- Close to magnetic fields

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Cleaning

Clean only with a soft, dry cloth.

Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling

Do not apply excessive force to the switches or controls.

Do not allow paper, metallic, or other objects to enter the instrument. If this happens, unplug the AC adapter from the wall outlet. Then have the instrument inspected by qualified service personnel.

Disconnect all cables before moving the instrument.

Contents

Panel Description

Front Panel.....	4
Rear Panel	4

Setup

Connect the pads and the pedal	5
--------------------------------------	---

Connections

Connect to audio equipment	6
Connect a CD player, etc. (aux in jack)	6
Connect head	6
Connect the power supply jack	6
MIDI and USB	6

MENU

menu tree	7
-----------------	---

Operation

Switch the power ON	7
Auto Power Off	7
Set the main volume	7

Pattern

Select a pattern	8
Adjust the accompaniment volume	8
Adjust the drum volume	8

Drum Kit

Select a kit	9
Adjust the kit volume	9

Switch reverb on/off	9
----------------------------	---

Voice

Select the voice	10
Adjust the voice volume	10
Adjust the MIDI note	11

Tempo

Adjust the tempo	11
------------------------	----

Click

Adjust the click time signature	12
Adjust the click interval	12
Adjust the click instrument	12
Adjust the click volume	12

Restore the factory preset..... 13

Play the demo..... 13

Play the pattern 13

Play the click 13

Appendices

Specifications	14
Preset drum kit list	15
Drum Instrument List	15
Preset Pattern List	15
GM backing instrument list	16
GM Drum Kit List	18
MIDI Implementation Chart	19

Panel Description

Front Panel

1 MASTER VOLUME KNOB

Control the volume of the phone and line out.
Turn it clockwise to increase the volume and anticlockwise to decrease the volume.

2 [START/STOP] BUTTON

Start or stop pattern playback.

3 3-DIGIT LED DISPLAY

3-digit LED and LED indicators

4 [CLICK] BUTTON

Press the [click] button to start/stop the click.
Hold down the [click] button for 2 seconds to enter demo mode and play the demo.

5 [MODE] BUTTON

Press the [mode] button to select the mode from PATTERN, KIT, VOICE, CLICK.


6 PAGE BUTTON

Press the [page] button to browse the menu pages of the currently selected mode.

Press both [mode] and [page] buttons, the 3-digit LED will display the tempo page, it will temporarily display for 3 seconds, then press [+] or [-] to adjust the volume.

7 [+]/[-] BUTTON

Press the [+]/[-] button to adjust the parameters.



Rear Panel

8 POWER SUPPLY JACK (DC IN 9V)

Connect an AC adapter to this jack.

9 POWER SWITCH

Turn the power on/off.

10 USB PORT

Connect to computer.

11 MIDI OUT JACK

Connect to external sound module.

12 LINE OUTPUT JACKS (R, L/MONO)


Made up of right channel output and left channel output which is also used as mono line output.

13 AUX IN

Connect to an external sound source.

14 PHONES JACK

Connect a pair of stereo headphones to this jack.
(Connecting the headphones will not mute the output jack.)



Caution


To prevent electric shock and damage to the device, make sure the power is switched OFF on the drum and all related devices before making any connections.

Connecting Pads and Pedals

Using the provided cables, connect the cable marked with the corresponding drum pads, cymbal pads, and pedals. (See the illustration below for reference)

Note:


1. The sound of the hi-hat pad is controlled by the hi-hat pedal. Similar to a real drum kit, the hi-hat pad functions as an 'open hi-hat' when the pedal is released. When the pedal is stepped, it functions as a 'closed hi-hat'.
2. The valid striking area of the cymbal pad (ride, crash, or hi-hat) is near the edge of the pad, which is different from other pads.




Connections

Connect to audio equipment

1. When you want to listen to the voices with an amplifier, connect amplifiers with the Output L/MONO and R jacks on the rear panel. (For monaural playback, use the L/MONO jack; for stereo playback, connect both L/MONO and R jacks.)
2. The volume is adjusted with the VOLUME knob.




1. The audio output of a CD player or other audio source connected to the AUX IN jack on the rear panel can be mixed with the sound of the drum. This function that let you play along with a favorite song.
2. The volume of the external signal is adjusted with the VOLUME knob.



Connect headphones

An optional set of stereo headphones can be connected to the PHONES jack located on the rear panel of the drum module.

* Adjust the volume to a comfortable level.




Connect the power supply jack

Make sure the power is switched OFF and connect the power adapter to the DC IN jack on the rear panel.

Note:

1. To protect the speakers, amplifier, and drum module from damage, turn the volume knob to the minimum volume level before turning the power ON.
2. Make sure the power is switched OFF when connecting the drum module to external devices.



MIDI and USB

MIDI stands for Musical Instrument Digital Interface, which is a worldwide standard communication interface that enables electronic musical instruments and computers (of all brands) to communicate with each other so that MIDI commands and other data can pass between them. This exchange of information makes it possible to create a system of MIDI instruments and devices that offer far greater versatility and control than is available with isolated instruments. Whether you interface with computers, sequencers, expanders or other controllers, your musical horizons will be greatly enhanced.

MIDI connection

MIDI OUT: This terminal transmits data from this instrument to other MIDI devices.

USB connection


The USB connector allows you to connect the module directly to your computer. It can be connected without driver installation under Windows XP, Vista, Windows 7, and MAC OSX. The module will be recognized as a "USB audio device" to receive and transmit MIDI messages through a single USB cable. USB is used only for MIDI messages (MIDI via USB).

Note: When the USB is connected to a computer, all MIDI messages will be received and transmitted via USB.



Menu

Menu tree



In the main menu there are 4 menu items

- PATTERN
- DRUM KIT
- VOICE
- CLICK


Operation

Press the [MODE] button to change the mode.
Press the [PAGE] button to select the page of the current mode.
Press the [+] / [-] button to adjust the parameters.

Switch the power ON

After confirming that all connections have been completed, rotate the volume knob to the left (minimum volume level) before switching the power on.

Set the power switch to the "ON" position to switch on the power.
The display shows the kit number and its indicator lights up.



Auto Power Off

In order to save energy, we have designed the "Automatic Shutdown" function. With this function, this product will shut down automatically when you have left it idle for more than 15 minutes. If you don't need this function, just press and hold the [START/STOP] button and then turn the drum on. You will also see the screen temporarily displaying "PoF" for 3 seconds before entering the main menu, which indicates that the "Automatic shutdown" function is turned off. This feature will reset to factory settings by rebooting the device. Please note that the device may consume more power when this feature is disabled. Power consumption after automatic shutdown: < 0.3 W (less than 0.3 W)



Set the main volume

While hitting a pad, gradually rotate the volume knob until a comfortable volume level is reached.



Pattern


In pattern mode, there are 3 pages:

1. Pattern number (1- 40, default 1)
2. Pattern accompaniment volume (0-32)
3. Pattern drum volume (0-32)

Select a pattern

In pattern mode, pattern number (001-040, default 001)


1. Press the [MODE] button to select the pattern mode, the pattern LED indicator will light up, and the 3-digit LED will display the pattern number (001).
2. Press the [+] or [-] button to adjust the value. Range: (001 to 040)



Adjust the accompaniment volume

In pattern mode, pattern accompaniment volume (0-032)


1. Press the [MODE] button to select the pattern mode, the pattern LED indicator will light up.
2. Press the [PAGE] button to select the accompaniment volume page; the 3-digit LED will display the accompaniment volume (A22).
3. Press the [+] or [-] button to adjust the value. Range: (0 to 32).



Adjust the drum volume

In pattern mode, pattern drum volume (0-032)

1. Press the [MODE] button to select the pattern mode, the pattern LED indicator will light up,
2. Press the [PAGE] button to select the drum volume page, the 3-digit LED will display the drum volume (d22).
3. Press [+] or [-] to adjust the value. Range: (0 to 32)



Drum Kit


In kit mode, there are 3 pages:

1. Kit number (001-010, default 1).
2. Kit volume (0-32).
3. Kit reverb: (on/off, default on).

Select a kit

In kit mode, kit number (001-010, default 1).


1. Press the [MODE] button to select the kit mode, the kit LED indicator will light up, and the 3-digit LED will display the kit number (001).
2. Press [+] or [-] to adjust the value.
Range: (001-010).



Adjust the kit volume


In kit mode, kit volume (0-32).

1. Press the [MODE] button to select the kit mode, the kit LED indicator will light up.
2. Press the [PAGE] button to select the kit volume page, the 3-digit LED will display the kit volume (L30).
3. Press [+] or [-] to adjust the value (Automatic save).
Range: (0 to 32).




Switch reverb on/off

1. Press the [MODE] button to select the kit mode; the kit LED indicator will light up.
2. Press the [PAGE] button to select the kit reverb page, The reverb effect can be turned on or off by pressing the [+] or [-] button.



PAGE 3



Voice

In voice mode, there are 3 pages:

1. Voice number: (1-108).
2. Voice volume: (0-32).
3. Midi note: (0-99).



Select the voice

In voice mode, voice number: (1-108).

1. Press the [MODE] button to select the voice mode.
the voice LED indicator will light up, strike a drum pad, and the 3-digit LED will display the voice number.
2. Press [+] or [-] to adjust the value (automatic save).
Range: (001 to 108).

NOTE:

When you select a voice for hi-hit drum, you can only select the hi-hat group voices from group 1 to group 4 (automatic save), the display is: (H-I).



Adjust the voice volume

In voice mode, voice volume: (0-32).

1. Press the [MODE] button to select the voice mode; the voice LED indicator will light up.
2. Press the [PAGE] button to select the voice volume page, strike a drum pad, the 3-digit LED will display the voice volume (L30).
3. Press [+] or [-] to adjust the value (automatic save).
Range: (0 to 32).



Adjust the MIDI note

In voice mode, MIDI note: (0-99).

1. Press the [MODE] button to select the voice mode; the voice LED indicator will light up.
2. Press [PAGE] button to select the midi note page, strike a drum pad, the 3-digit LED will display the midi note (n48).
3. Press [+] or [-] to adjust the value (automatic save).
Range: (0 to 99).



THE DEFAULT MIDI NOTE:


NO.	NAME	NOTE
1	CRASH1	49
2	TOM 1	48
3	TOM 2	45
4	TOM 3	43
5	RIDE	51
6	KICK	36
7	SNARE	38
8	HIHAT CLOSE	42
9	HIHAT OPEN	46
10	HIHAT PEDAL	44

Tempo

The tempo range is 30-280

Adjust the tempo

1. Press both [MODE] and [PAGE] buttons, the 3-digit LED will display the tempo page, it will temporarily display for 3 seconds.
2. Press [+] or [-] to adjust the value.



Click

In click mode, there are 4 pages:


1. Time signature: (1/4-7/4, 3/8, 6/8).
- 2.
3. Instrument: (1-5, default 1).
4. Click volume: (0-32).

Adjust the click time signature

In click mode, Time signature: (1/4-7/4, 3/8, 6/8).

1. Press the [MODE] button to select the click mode; the click LED indicator will light up.
2. Press the [PAGE] button to select the click time signature page, the 3-digit LED will display the click time signature (4-4).
3. Press [+] or [-] to adjust the value.
Range: (1/4-7/4 or 3/8 or 6/8).


Note: The click time signature will follow the pattern; when the pattern is playing, it cannot be edited.



Adjust the click interval

In click mode, interval: (1/4, 1/8, 1/12, 1/16, 1/24, default 1/4).


1. Press [MODE] button to select the click mode, the click LED indicator will light up.
2. Press the [PAGE] button to select the click interval page, the 3-digit LED will display the click interval (--4).
3. Press the [+] or [-] button to adjust the value.
Range: (--4 to -24).



Adjust the click instrument

In click mode, instrument: (1-5, default 1).

1. Press the [MODE] button to select the click mode, the click LED indicator will light up.
2. Press the [PAGE] button to select the click instrument page, the 3-digit LED will display the click instrument (CL1).
3. Press [+] or [-] to adjust the value.
Range: (CL1 to CL5).



Adjust the click volume

In click mode, click volume: (0-32).

1. Press [MODE] button to select the click mode, the click LED indicator will light up.
2. Press [PAGE] button to select the click volume page, the 3-digit LED will display the click volume (L24).
3. Press [+] or [-] to adjust the value.
Range: (0 to 32)



Restore the factory preset

Restoring the factory preset can be implemented by following operations:


Turn on the power with both [+] and [-] unreleased.

This function will replace the current settings of the following parameters with their default preset values:

Kit volume, voice number, voice volume, and MIDI note.

Play the " " demo

1. Hold down the [CLICK] button for 2 seconds to enter the demo and play the demo; the 3-digit LED will display the demo "dE".
2. Press the [START/STOP] button to stop the demo playing.



Play the pattern

1. Press the [START/STOP] button to play the pattern.
2. Press the [START/STOP] button again to stop the pattern playing.

Play the " " click

1. Press the [CLICK] button to start the click, the click indicator will flash follow the beat.
2. Press the [CLICK] button again to stop the click.

Specifications

Drum Pad

4 drum pads, 3 cymbal pads, 1 hi-hat control pedal, 1 kick pedal

Preset drum kits

10 preset kits

Drum instrument

10

Preset patterns

4

Control

MIDI OUT, POWER SWITCH, USB, PHONES, START/STOP, PATTERN, KIT, VOICE, CLICK, MODE, PAGE, DEMO, TEMPO, VOLUME, + / -

Display

LED display

Connections

PHONES
AUX IN
OUTPUT (R & L/MONO)
MIDI OUT
USB
ON/OFF

Power supply

AC adapter (⎓ 9V)

Preset drum kit list

No	Name
001	Acoustic
002	Standard
003	Rock
004	Standard 2
005	Radio
006	Jazz
007	Brush
008	Electronic
009	808
010	House

Drum Instrument List

[illegible]

Preset Pattern List

No.	Tempo	Kit		Tempo	Kit		
001	Fusion 1	103	1	021	Swing	172	6
002	Electronic & Funk	116	9	022	Latin jazz 2	12	7
003	Modern Pop	136	1	023	Big Band 2	152	6
004	Hip hop	110	9	024	3/4 jazz	120	7
005	Latin jazz 1	1	7	025	Jazz	150	7
006	Funk 1	120	5	026	6/8 Ballad	96	3
007	Big Band 1	170	6	027	Pop ballad	8	3
008	Funk 2	112	1	028	Pop Bossa	120	2
009	Pop Funk 1	112	1	029	16Beat Pop	120	5
010	Fusion 2	11	1	030	Pop Shuffle	86	5
011	Funk 3	120	5	031	Samba	236	1
012	Fusion 3	108	1	032	Mambo	126	5
013	Fusion 4	116	1	033	Latin rock	136	1
014	Pop Funk 2	106	5	034	Latin Pop	126	5
015	R&B	86	9	035	Guitar Bossa	84	5
016	Drum & Bass 1	16	9	036	Country Blues	1	3
017	Break Beat	108	5	037	Rock	100	1
018	Dance	130	9	038	Reggae	78	1
019	Drum & Bass 2	170	1	039	60s rock	120	2
0	Latin dance	126	5	040	Blues	96	2
				Demc	Funk	100	1

GM backing instrument List

PIANO

- 1 Acoustic Grand Piano
- 2 Bright Acoustic Piano
- 3 Electric Grand Piano
- 4 Honky-Tonk Piano
- 5 E.Piano 1
- 6 E.Piano 2
- 7 Harpsichord
- 8 Clavi

MALLET

- 9 Celesta
- 10 Glockenspiel
- 11 Music box
- 12 Vibraphone
- 13 Marimba
- 14 Xylophone
- 15 Tubular bells
- 16 Dulcimer

ORGAN

- 17 drawbar organ
- 18 Percussive Organ
- 19 Rock organ
- 20 Church Organ
- 21 Reed organ
- 22 Accordion
- 23 Harmonica
- 24 Tango accordion

GUITAR

- 25 nylon guitar
- 26 Steel Guitar
- 27 Jazz Guitar
- 28 Clean Guitar
- 29 Muted Guitar
- 30 Overdriven Guitar
- 31 Distortion Guitar
- 32 Guitar harmonics

BASS

- 33 Acoustic Bass
- 34 Finger Bass
- 35 Pick Bass
- 36 Fretless bass
- 37 Slap bass 1
- 38 Slap bass 2
- 39 Synth Bass 1
- 40 Synth Bass 2

STRINGS

- 41 Violin
- 42 Viola
- 43 Cello
- 44 Double bass
- 45 Tremolo strings
- 46 Pizzicato Strings
- 47 Orchestral Harp
- 48 Timpani

STRINGS ENSEMBLE

- 49 Strings Ensemble 1
- 50 Strings Ensemble 2
- 51 Synth Strings 1
- 52 Synth Strings 2
- 53 Choir Aahs
- 54 Voice Oohs
- 55 Synth Voice
- 56 Orchestra Hit

BRASS

- 57 Trumpet
- 58 Trombone
- 59 Tuba
- 60 Muted trumpet
- 61 French horn
- 62 Brass Section
- 63 Synth Brass 1
- 64 Synth Brass 2

REED

- 65 Soprano Sax
- 66 Alto Sax
- 67 Tenor Sax
- 68 Baritone saxophone
- 69 Oboe
- 70 English horn
- 71 Bassoon
- 72 Clarinet

PIPE

- 73 Piccolo
- 74 Flute
- 75 Recorder
- 76 Pan flute
- 77 Blown Bottle
- 78 Shakuhachi
- 79 Whistle
- 80 Ocarina

LEAD

- 81 Lead1 (square)
- 82 Lead2 (sawtooth)
- 83 Lead3 (calliope)
- 84 Lead4 (chiff)
- 85 Lead 5 (charang)
- 86 Lead6 (voice)
- 87 Lead7 (fifths)
- 88 Lead8 (bass & Lead)

PAD

- 89 Pad1 (new age)
- 90 Pad2 (warm)
- 91 Pad3 (polysynth)
- 92 Pad4 (choir)
- 93 Pad5 (bowed)
- 94 Pad6 (metallic)
- 95 Pad7 (halo)
- 96 Pad8 (sweep)

EFFECTS

- 97 FX1 (rain)
- 98 FX2 (soundtrack)
- 99 FX3 (crystal)
- 100 FX4 (atmosphere)
- 101 FX5 (brightness)
- 102 FX6 (goblins)
- 103 FX7 (echoes)
- 104 FX8 (sci-fi)

ETHNIC

- 105 Sitar
- 106 Banjo
- 107 Shamisen
- 108 Koto
- 109 Kalimba
- 110 Bagpipe
- 111 Fiddle
- 112 Shanai

PERCUSSIVE

- 113 Tinkle Bell
- 114 Agogo
- 115 Steel drums
- 116 Wood Block
- 117 Taiko drum
- 118 Melodic tom
- 119 Synth drum
- 120 Reverse cymbal

SOUND EFFECTS

- 121 Guitar Fret Noise
- 122 Breath Noise
- 123 Seashore
- 124 Bird Tweet
- 125 Telephone Ring
- 126 Helicopter
- 127 Applause
- 128 Gunshot

GM drum kit list

NET NO	Standard 1 (bank 0)	Standard 2 (bank 4)	Room (bench 8)	Rock (bank 16)	Funk (bank 17)
27-D#1	High Q	<-	<-	<-	<-
28-E1	Slap	<-	<-	<-	<-
29-F1	Scratch Push	<-	<-	<-	<-
30-F#1	Scratch Pull	<-	<-	<-	<-
31-G1	Sticks	<-	<-	<-	<-
32-G#1	Square Click	<-	<-	<-	<-
33-A1	Metronome Click	<-	<-	<-	<-
34-A#1	Metronome Bell	<-	<-	<-	<-
35-B1	Acoustic Bass Drum	<-	Room Bass Drum 1	Rock Bass Drum 1	Funk Bass Drum 1
36-C2	Standard 1 Bass Drum	Standard 2 Bass Drum	Room Bass Drum 2	Rock Bass Drum 2	Funk Bass Drum 2
37-C#2	Side Stick	<-	<-	<-	<-
38-D2	Standard 1 snare	Standard 2 snare	Room snare	Rock snare	Funk snare
39-D#2	Hand Clap	<-	<-	<-	<-
40-E2	Standard 1 snare rim	Standard 2 snare rim	Room Snare Rim	Rock Snare Rim	Funk Snare Rim
41-F2	Standard 1 Tom 6	Standard 2 tom 6	Room Tom 6	Rock Tom 6	Funk Tom 6
42-F#2	Standard 1 Hi-hat Close	Standard 2 Hi-hat Close	Room Hi-hat Close	Rock Hi-hat Close	Wireless hi-hat close
43-G2	Standard 1 tom 5	Standard 2 tom 5	Room tom 5	Rock Tom 5	Funk Tom 5
44-G#2	Standard 1 Hi-hat pedal	Standard 2 hi-hat pedal	Room hi-hat pedal	Rock hi-hat pedal	Funk hi-hat pedal
45-A2	Standard 1 tom 4	Standard 2 tom 4	Room Tom 4	Rock Tom 4	Funk Tom 4
46-A#2	Standard 1 Hi-hat Open	Standard 2 Hi-hat Open	Room hi-hat open	Rock hi-hat open	Funk hi-hat open
47-B2	Standard 1 Tom 3	Standard 2 Tom 3	Room Tom 3	Rock Tom 3	Funk Tom 3
48-C3	Standard 1 Tom 2	Standard 2 Tom 2	Room Tom 2	Rock Tom 2	Funk Tom 2
49-C#3	Standard 1 Crash 1	Standard 2 Crash 1	Room Crash 1	Rock crash 1	Funk crash 1
50-D3	Standard 1 Tom 1	Standard 2 Tom 1	Room Tom 1	Rock Tom 1	Funk Tom 1
51-D#3	Standard 1 Ride	Standard 2 Ride	Room Ride	Rock Ride	Funk Ride
52-E3	Chinese Cymbal 1	<-	<-	<-	<-
53-F3	Ride Bell	<-	Room Ride Bell	Rock Ride Bell	<-
54-F#3	Tambourine	<-	<-	<-	<-
55-G3	Splash cymbal	<-	Room Splash Cymbal	Rock Splash Cymbal	<-
56-G#3	Standard 1 Cowbell	Standard 2 Cowbell	Room Cowbell	Rock cowbell	<-
57-A3	Standard 1 crash 2	Standard 2 crash 2	Room Crash 2	Rock Crash 2	Funk Crash 2
58-A#3	Vibra-slap	<-	<-	<-	<-
59-B3	Ride Cymbal	<-	<-	<-	<-
60-C4	Hi Bongo	<-	<-	<-	<-
61-C#4	Low bongo	<-	<-	<-	<-
62-D4	Mute Hi Conga	<-	<-	<-	<-
63-D#4	Open Hi Conga	<-	<-	<-	<-
64-E4	Low Conga	<-	<-	<-	<-
65-F4	High Timbale	<-	<-	<-	<-
66-F#4	Low Timbale	<-	<-	<-	<-
67-G4	High Agogo	<-	<-	<-	<-
68-G#4	Low Agogo	<-	<-	<-	<-
69-A4	Cabasa	<-	<-	<-	<-
70-A#4	Maracas	<-	<-	<-	<-
71-B4	Short Whistle	<-	<-	<-	<-
72-C5	Long Whistle	<-	<-	<-	<-
73-C#5	Short Guiro	<-	<-	<-	<-
74-D5	Long Guiro	<-	<-	<-	<-
75-D#5	Claves	<-	<-	<-	<-
76-E5	Hi Wood Block	<-	<-	<-	<-
77-F5	Low Wood Block	<-	<-	<-	<-
78-F#5	Mute Cuica	<-	<-	<-	<-
79-G5	Open Cuica	<-	<-	<-	<-
80-G#5	Mute Triangle	<-	<-	<-	<-
81-A5	Open Triangle	<-	<-	<-	<-
82-A#5	Shaker	<-	<-	<-	<-
83-B5	Jingle Bell	<-	<-	<-	<-
84-C6	Bell Tree	<-	<-	<-	<-
85-C#6	Castanets	<-	<-	<-	<-
86-D6	Mute Surdo	<-	<-	<-	<-
87-D#6	Open Surdo	<-	<-	<-	<-

GM Drum Kit List

NET NO	Electronic (bank 24)	808 (bank 25)	House (bank 28)	Jazz (bank 32)	Brush (bank 40)
27-D#1	<-	<-	<-	<-	<-
28-E1	<-	<-	<-	<-	<-
29-F1	<-	<-	<-	<-	<-
30-F#1	<-	<-	<-	<-	<-
31-G1	<-	<-	<-	<-	<-
32-G#1	<-	<-	<-	<-	<-
33-A1	<-	<-	<-	<-	<-
34-A#1	<-	<-	<-	<-	<-
35-B1	Electronic Bass Drum 1	808 Bass Drum 1	House Bass Drum 1	Jazz Bass Drum 1	Brush bass drum 1
36-C2	Electronic Bass Drum 2	808 Bass Drum 2	House Bass Drum 2	Jazz Bass Drum 2	Brush Bass Drum 2
37-C#2	<-	<-	<-	<-	<-
38-D2	Electronic Snare	808 Snare	House Snare	Jazz Snare	Brush Snare
39-D#2	<-	<-	House Hand Clap	<-	<-
40-E2	Electronic Snare Rim	808 Snare Rim	House Snare Rim	Jazz Snare Rim	Brush Snare Rim
41-F2	Electronic Tom 6	808 Tom 6	House Tom 6	Jazz Tom 6	Brush Tom 6
42-F#2	Electronic Hi-hat Close	808 Hi-hat Close	House hi-hat close	Jazz hi-hat close	<-
43-G2	Electronic Tom 5	808 Tom 5	House Tom 5	Jazz Tom 5	Brush Tom 5
44-G#2	Electronic Hi-hat Pedal	808 Hi-hat Pedal	House hi-hat pedal	Jazz Hi-hat Pedal	<-
45-A2	Electronic Tom 4	808 Tom 4	House Tom 4	Jazz Tom 4	Brush Tom 4
46-A#2	Electronic Hi-hat Open	808 Hi-hat Open	House Hi-hat Open	Jazz Hi-hat Open	<-
47-B2	Electronic Tom 3	808 Tom 3	House Tom 3	Jazz Tom 3	Brush Tom 3
48-C3	Electronic Tom 2	808 Tom 2	House Tom 2	Jazz Tom 2	Brush Tom 2
49-C#3	<-	808 Crash 1	<-	<-	Brush crash 1
50-D3	Electronic Tom 1	808 Tom 1	House Tom 1	Jazz Tom 1	Brush Tom 1
51-D#3	<-	<-	<-	Jazz Ride	Brush Ride
52-E3	<-	<-	<-	<-	<-
53-F3	<-	<-	<-	<-	<-
54-F#3	<-	<-	<-	<-	<-
55-G3	<-	<-	<-	<-	<-
56-G#3	<-	<-	<-	<-	<-
57-A3	<-	808 Crash 2	<-	Chinese Cymbal 2	Brush Crash 2
58-A#3	<-	<-	<-	<-	<-
59-B3	<-	<-	<-	<-	<-
60-C4	<-	<-	<-	<-	<-
61-C#4	<-	<-	<-	<-	<-
62-D4	<-	808 Mute Hi Conga	<-	<-	<-
63-D#4	<-	808 Open Hi Conga	<-	<-	<-
64-E4	<-	808 Low Conga	<-	<-	<-
65-F4	<-	<-	<-	<-	<-
66-F#4	<-	<-	<-	<-	<-
67-G4	<-	<-	<-	<-	<-
68-G#4	<-	<-	<-	<-	<-
69-A4	<-	<-	<-	<-	<-
70-A#4	<-	808 Maracas	<-	<-	<-
71-B4	<-	<-	<-	<-	<-
72-C5	<-	<-	<-	<-	<-
73-C#5	<-	<-	<-	<-	<-
74-D5	<-	<-	<-	<-	<-
75-D#5	<-	808 Claves	<-	<-	<-
76-E5	<-	<-	<-	<-	<-
77-F5	<-	<-	<-	<-	<-
78-F#5	<-	<-	<-	<-	<-
79-G5	<-	<-	<-	<-	<-
80-G#5	<-	<-	<-	<-	<-
81-A5	<-	<-	<-	<-	<-
82-A#5	<-	<-	<-	<-	<-
83-B5	<-	<-	<-	<-	<-
84-C6	<-	<-	<-	<-	<-
85-C#6	<-	<-	<-	<-	<-
86-D6	<-	<-	<-	<-	<-
87-D#6	<-	<-	<-	<-	<-

MIDI Implementation Chart

	Function...	Transmitted	Recognized	Remarks
Basic Channel	Default Changed	10 ch X	1-16 X	
Mode	Default Messages Altered	X *****	*****	
Note Number:	True voice	0-127 *****	0 0	
Velocity	Note on Note off	O 99H, V=1-127 O (9 9H. V=0)	0-127 0-127	
After Touch	Key Channels	X X	X X	
Pitch Bend		X	O	
Control Change	0 1 5 6 7 10 11 64 65 66 67 8 81 91 93 120 121 123	X X X X X X X X X X X X X X X X X	O O O O O O O O O O O O O O O O O	Bank Select Modulation Portamento Time Data Entry Volume Pan Expression Sustain pedal Portamento ON/OFF Sostenuto pedal Soft pedal Reverb Program Chorus program Reverb level Chorus level All sound OFF Reset all controllers All notes OFF
Program Change		X	O	
System Exclusive		X	O	
System Common	: Song Position : Song Select : Tune	X X	X X	
System Real time	: Clock : Commands	O	X	START \ STOP
Aux Messages	: Local ON/OFF : All Notes OFF : Active Sense : Reset	X X O X	X X X X	

O : YES

X : NO

WEEE Declaration / Disposal



Your product is designed and manufactured with high-quality materials and components that are recyclable and can be reused. The symbol means that your product should be disposed of separately from household waste when it reaches the end of its service life. Please dispose of this equipment at your local collection point or recycling center. Please help to protect the environment in which we all live.

All specifications and appearances are subject to change without notice. All information was correct at the time of printing. Musikhaus Kirstein GmbH does not guarantee the accuracy or completeness of any description, photograph, or statement contained in this manual. Printed colors and specifications may vary slightly from the product. Products from Musikhaus Kirstein GmbH are only sold through authorized dealers. Distributors and dealers are not agents of Musikhaus Kirstein GmbH and have no authority to bind Musikhaus Kirstein GmbH legally in any way. This manual is protected by copyright. Any copying or reprinting, even in excerpts, is only permitted with the written consent of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, even in altered form.



Musikhaus Kirstein GmbH

Bernbeurener Strasse 11

86956 Schongau

Phone: 0049-909494-0

Fax: 0049-909494-19

www.kirstein.de

