

CLASSIC CANTABILE

UP-1 Digitalpiano



Bedienungsanleitung / User manual

Version: 07/2025

Vielen Dank, dass Sie sich für dieses Produkt entschieden haben.

Um sicherzustellen, dass Sie mit diesem Produkt voll und ganz zufrieden sind, lesen Sie sorgfältig und verstehen Sie diese Bedienungsanleitung, bevor Sie dieses Instrument verwenden. Bewahren Sie diese Bedienungsanleitung an einem sicheren Ort auf. Die Bedienungsanleitung muss an alle nachfolgenden Anwender weitergegeben werden.



Bedienungsanleitung beachten!



WARNUNG

Mit dem Signalwort **WARNUNG** sind die Gefahren gekennzeichnet, die ohne Vorsichtsmaßnahmen zu schweren Verletzungen führen können.



HINWEIS

Mit dem Signalwort **HINWEIS** sind allgemeine Vorsichtsmaßnahmen gekennzeichnet, die im Umgang mit dem Produkt beachtet werden sollen.



HINWEIS

Bilder und Bildschirmdarstellungen in dieser Bedienungsanleitung können vom Erscheinungsbild des tatsächlichen Produkts geringfügig abweichen, solange dies keine negativen Auswirkungen auf die technischen Eigenschaften und Sicherheit des Produkts hat.



HINWEIS

Alle personenbezogenen Formulierungen in dieser Bedienungsanleitung sind geschlechtsneutral zu betrachten.

Diese Bedienungsanleitung gilt für mündige Personen und Nutzer, die von einer für ihre Sicherheit verantwortlichen Person beaufsichtigt oder in die Bedienung des Gerätes eingewiesen wurden und nachgewiesen haben mit dem Gerät umgehen zu können.



WARNUNG

Kinder sollten beaufsichtigt werden, um sicherzustellen, dass sie dieses Gerät nicht als Spielzeug verwenden. Lassen Sie Kinder niemals unbeaufsichtigt mit dem Verpackungsmaterial spielen.



WARNUNG

Gefahr der Sachbeschädigung! Wir haften nicht für Unfälle, die infolge der Nichtbeachtung der Sicherheitshinweise oder durch falsche Handhabung auftreten.

Alle Informationen in dieser Bedienungsanleitung wurden nach bestem Wissen und Gewissen kontrolliert. Weder Autor noch Herausgeber können jedoch für Schäden haftbar gemacht werden, die in Zusammenhang mit der Verwendung dieser Bedienungsanleitung stehen.

Sonstige, in diesem Dokument aufgeführte Produkt-, Marken- und Unternehmensbezeichnungen können die Warenzeichen ihrer jeweiligen Eigentümer sein. Die Einhaltung sämtlicher anwendbarer Urheberrechtsgesetze liegt in der Verantwortung des Anwenders dieses Dokuments.



Vorsicht

Bitte beachten Sie folgende grundlegenden Hinweise, um sich oder andere nicht zu gefährden und Schäden an externen Geräten zu vermeiden.



Warnhinweise

Bauen Sie das Instrument nicht auseinander und nehmen Sie keine Modifikationen daran vor. Dies könnte Verletzungen durch Stromschlag zur Folge haben. Betrauen Sie eine Fachwerkstatt mit eventuell nötigen Service- und Wartungsarbeiten oder wenden Sie sich an Ihren Händler.

Wenn Sie feststellen, dass das Stromkabel deutliche Gebrauchsspuren aufweist, das Gerät Fehlfunktionen aufweist, verbrannt riecht oder raucht, ziehen Sie umgehend den Stecker aus der Steckdose und beauftragen Sie einen Techniker mit der Reparatur.

Bevor Sie das Instrument reinigen, sollten Sie es vom Strom trennen.

Stellen Sie das Instrument stets auf eine ebene, stabile Oberfläche, um einen sicheren Stand zu gewährleisten.

Benutzen Sie das Instrument nicht in feuchter oder nasser Umgebung.

Stellen Sie keine Gefäße darauf, die mit Flüssigkeiten gefüllt sind, wie z.B. Vasen, Gläser oder Flaschen.

Legen Sie keine kleinen Gegenstände darauf, die hineinrutschen könnten, wie z.B. Haarnadeln, Nähnadeln oder Münzen.

Stellen Sie keine brennenden Kerzen auf das Instrument.



Vorsichtsmaßnahmen

Um Schäden am Instrument zu vermeiden, stellen Sie es nicht an Plätze mit hohen Temperaturen oder viel Staub, stellen Sie es nicht direkt neben eine Klimaanlage und vermeiden Sie direkte Sonneneinstrahlung.

Stellen Sie das Instrument nicht in die Nähe von anderen elektrischen Geräten, um Interferenzen zu vermeiden.

Wenden Sie im Umgang mit dem Instrument keinerlei Gewalt an und stellen Sie keine schweren Gegenstände auf das Gerät.

Trennen Sie das Instrument vom Strom, wenn Sie es längere Zeit nicht benutzen. Um das Gerät vom Strom zu trennen, ziehen Sie bitte am Stecker, nicht am Kabel. Gehen Sie bitte vorsichtig mit dem Stromkabel um. Es sollte nicht in der Nähe von Heizkörpern liegen, Sie sollten keine schweren Gegenstände daraufstellen und es so verlegen, dass keine Personen darauf treten oder darüber fallen könnten.

Bitte beachten Sie, dass dauernde hohe Lautstärke Ihr Gehör dauerhaft schädigen kann.

Passen Sie daher die Lautstärke sorgfältig an.



Netzteil

Bitte schließen Sie das mitgelieferte Netzteil an eine Steckdose mit der richtigen Spannung an. Schließen Sie es nicht an andere Netzspannungen an als die, für welche das Instrument vorgesehen ist. Ziehen Sie den Netzstecker, falls Sie das Produkt für längere Zeit nicht benutzen oder wenn es zu einem Gewitter kommt.

© 2025


Diese Bedienungsanleitung ist urheberrechtlich geschützt. Die Vervielfältigung dieser Bedienungsanleitung, auch auszugsweise, ist nur mit Genehmigung der Musikhaus Kirstein GmbH gestattet. Gleiches gilt für die Vervielfältigung oder das Kopieren von Bildern, auch in geänderter Form.

Inhalt


Zusammenbau	6
Frontseitiges Anschlusspanel	9
USB to Host	9
USB to Device	9
Phones	9
Mic In / AUX In	10
AUX Out	10
Bedienelemente	11
Power-Schalter und Drehregler für Volume, Brilliance und Tempo	11
Power	11
Gesamt-Lautstärke (MASTER)	11
Mikrofon-Lautstärke (MIC)	11
Piano-Lid Simulation (BRILLIANCE)	11
Geschwindigkeit (TEMPO)	12
Bedieneinheit für Metronom, Songwiedergabe und Aufnahmefunktion	12
Metronom (METRO)	12
Aufnahme (REC, LEFT, RIGHT, START/STOP)	12
1. Einfache Aufnahme in den internen Speicher (MIDI)	12
2. Kombinierte Aufnahme in den internen Speicher (MIDI)	13
3. Aufnahme auf einem externen Speichermedium (mp3)	13
Song-Wiedergabe (SONG, LEFT, RIGHT, START/STOP)	14
USB-Speicher (USB, START/STOP)	14
Bedieneinheit für Voice-Auswahl und weitere Funktionen	14
Auswahl der Klangfarbe (VOICE)	15
Demo der jeweiligen Klangfarbe (VOICE DEMO)	15
Kombination zweier Klangfarben (DUAL)	15
Kombination zweier Klangfarben (SPLIT)	15

Teilen der Klaviatur (TWINOVA)	16
Piano-Modus (PIANO)	16
Funktionsmenü (FUNKTION).....	16
1. Allgemeine Einstellungen	16
Transponieren (TRANSPOSE)	16
Oktavieren (OCTAVE R1, OCTAVE R2, OCTAVE L)	16
Anschlagsempfindlichkeit (TOUCH).....	16
Lautstärkeanteile (VOLUME R1, VOLUME R2, VOLUME L, VOLUME MUSIC).....	17
Taktart des Metronoms (METRONOME)	17
Lautsprecher EQ-Settings (SPEAKER EQ)	17
Saitenresonanz (STRING RES.).....	17
Effekte (REVERB TYPE, REVERB LEVEL, CHORUS TYPE, CHORUS LEVEL, MIC FX TYPE, MIC FX LEVEL)	17
Wiedergabemodus des Audio-Players (SONG LOOP)	17
Deaktivierung des internen Soundgenerators (LOCAL)	17
Tabelle - allgemeine Einstellungen.....	18
2. Weitere Einstellungen	18
MIDI-Out Kanäle (MIDI OUT CH).....	19
Auto-Power-Off (POWER OFF)	19
Zeit und Datumseinstellung (YEAR, MONTH, DAY, HOUR, MINUTE)	19
Reset (SYSTEM RESET)	19
Tabelle - weitere Einstellungen	19
Anschluss eines Computers oder Smart-Geräts.....	20
Trouble Shooting	21
Produktspezifikationen	22
Appendix	24
Voice-Liste	24
Song-Liste.....	24

Zusammenbau




Befestigen Sie zuerst die beiden Seitenteile **A** mit Hilfe der langen Schrauben **E** an der Pedalleiste **B** und verdecken Sie die Schraubenöffnungen mit den Plastikkappen **F**.



Bringen Sie nun die Rückwand **C** am Unterbau an und befestigen diese mit Hilfe der kurzen, spitzen Schrauben **G** zu den Seitenteilen und zur Pedalleiste.






Legen Sie den Spieltisch **D** vorsichtig auf den Unterbau. Lassen Sie sich hierbei von einer zweiten Person helfen und achten Sie auf Ihre Finger. Befestigen Sie den Spieltisch sicher mit den zwei Kunststoffkopfschrauben **H** an den hinteren Metallwinkeln und mit den sechs kurzen Schrauben **K** an der Befestigungsleiste des Unterbaus. Hier kann es hilfreich sein, alle Schrauben erst handfest einzuschrauben und erst nachdem alle Schrauben in ihrer Position sind, diese festzuziehen.




Verbinden Sie nun das Pedalkabel **J** mit der Buchse an der Unterseite des Pianos und stecken Sie den Hohlstecker des Netzteils in die Netzteilbuchse an der Rückseite des Instruments.



Befestigen Sie, falls gewünscht, den Kopfhörerhalter **M** an der Rückseite der Connection-Box. Die beiden Löcher, für die dem Halter beiliegenden Mini-Schrauben, sind leicht zu ertasten.


Stellen Sie nun das Piano an den vorgesehenen Platz.

Achtung: Drehen Sie nun die Stützschraube **L** der Pedaleinheit bis zum Boden heraus.



► Es kann nützlich sein, die Verpackungsmaterialien für den Fall aufzubewahren, dass das Instrument an einen weit entfernten Ort transportiert werden muss.

Frontseitiges Anschlusspanel



USB to Host

Über die USB to Host Buchse können Sie Ihr Piano mittels eines USB A->B Kabels zu einem Computer verbinden.

USB to Device



Sie können einen USB-Stick benutzen, um Songs im mp3-Format aufzunehmen oder um Songs im mp3 oder MIDI-Format wiederzugeben. Es werden USB-Speicher von 2-128GB unterstützt. Der USB-Stick muss in FAT32 formatiert sein. Der Zugriff erfolgt im Root-Verzeichnis. Erstellen Sie keine Unterordner.



Phones


Die beiden Kopfhöreranschlüsse können gleichzeitig genutzt werden. Beim Anschluss eines Kopfhörers werden die Lautsprecher des Instruments automatisch stumm geschaltet. Achtung: Achten Sie auf eine angemessene Lautstärkeneinstellung. Zu hohe Lautstärke bzw. zu lange Nutzung von Kopfhörern kann Gehörschäden verursachen.



Mic In / AUX In

Mit dem **Mic-In** Eingang können Sie ein dynamisches Mikrofon über die Lautsprecher Ihres Pianos wiedergeben. Stellen Sie hierzu den **Wahlschalter auf die Position MIC**. Achtung: Je nach Qualität des Mikrofons kann es hierbei zu Rückkopplungseffekten kommen. Vermeiden Sie zu hohe Lautstärken und richten Sie das Mikrofon nicht zu den Lautsprechern des Pianos aus.

Mit dem **AUX In** Eingang können Sie Musiksignale einer externen Musikquelle über die Lautsprecher Ihres Pianos wiedergeben. Stellen Sie hierzu den **Wahlschalter auf die Position AUX IN**.




AUX Out

Mit dem AUX Out Anschluss können Sie Ihr Piano an einen Musikverstärker anschließen.

Bedienelemente

Power-Schalter und Drehregler für Volume, Brilliance und Tempo



Power

Mit dem Netzschalter nehmen Sie Ihr Instrument in Betrieb. Bitte schalten Sie Ihr Instrument bei Nichtbenutzung aus, um Energie zu sparen.

Dieses Instrument verfügt über eine Auto-Power-Off-Funktion. Um Energie zu sparen, schaltet sich das Piano selbständig aus, falls es für längere Zeit nicht benutzt wird.

Gesamt-Lautstärke (MASTER)

Mit diesem Drehregler können Sie die Lautstärke Ihres Pianos einstellen. Drehen Sie diesen Regler vor der Inbetriebnahme Ihres Instruments und vor dem Anschluss von Peripheriegeräten (Kopfhörer, Mikrofon, USB-Gerät/Stick, ext. Verstärker, Zuspielder, Aufnahmegerät) stets auf null und passen Sie die Lautstärke anschließend auf den gewünschten Wert an.

Mikrofon-Lautstärke (MIC)

Mit diesem Drehregler können Sie die Lautstärke eines angeschlossenen Mikrofons einstellen. Drehen Sie diesen Regler vor dem Anschließen eines Mikrofons stets auf null und passen Sie die Lautstärke anschließend auf den gewünschten Wert an.

Piano-Lid Simulation (BRILLIANCE)

Dieser Regler simuliert das Öffnen und Schließen des Pianodeckels eines echten Konzertflügels. Mit diesem Drehregler können Sie den Höhenanteil der Klangwiedergabe regeln. Drehen Sie den Regler nach links, um einen wärmeren Klang zu erreichen und nach rechts, für einen kühleren, brillanteren Klang.


Geschwindigkeit (TEMPO)

Drehen Sie diesen Regler, um das Tempo einzustellen.

Drücken Sie den Regler kurz, um zum Original-Tempo zurückzukehren.

Drücken Sie den Regler lang um von der Tempoanzeige in BPM (30-280 Beats per Minute) zur klassischen Tempobezeichnung (Grave bis Prestissimo) im Display umzuschalten. Die Tempoanzeige wechselt anschließend selbständig zur Standardanzeige (BPM) zurück.

Bedieneinheit für Metronom, Songwiedergabe und Aufnahmefunktion



Metronom (METRO)

Drücken Sie die METRO-Taste, um das Metronom zu starten. Drücken Sie die Taste METRO erneut, um das Metronom zu stoppen.

Die Geschwindigkeitseinstellung des Metronoms erfolgt über den Drehregler Tempo (siehe Geschwindigkeit (TEMPO)).

Das Taktmass des Metronoms kann bei Bedarf im Funktionsmenu geändert werden (siehe Funktionsmenü (FUNCTION)).

Das Metronomsignal wird nicht über die AUX OUT und die USB-to-Host Buchsen ausgegeben. Das Metronomsignal wird im Aufnahmemodus nicht mit aufgezeichnet.

Aufnahme (REC, LEFT, RIGHT, START/STOP)

1. Einfache Aufnahme in den internen Speicher (MIDI)

Das Piano verfügt über einen internen Speicher, welcher einen User-Song im MIDI-Format abspeichern kann. Um einen Song als MIDI-Datei im internen Speicher aufzunehmen, stellen Sie sicher, dass kein USB-Speichermedium im USB-Slot des Instrumentes steckt. Drücken Sie die Taste REC um das Instrument in Aufnahmebereitschaft zu versetzen. Befindet sich bereits eine Aufnahme im Speicher, erscheint die Meldung „Overwrite User Song?“ im Display. Folgen Sie den Anweisungen im Display, um die Aufnahme abubrechen, oder den gespeicherten Song zum Überschreiben

freizugeben. Die Aufnahmebereitschaft wird angezeigt, indem die „Rec“ Anzeige im Display blinkt und das Metronom startet (das Klicken des Metronoms dient lediglich zu Ihrer Orientierung, es wird nicht mit aufgezeichnet). Wählen Sie nun die gewünschte Metronom-Geschwindigkeit durch Drehen des Reglers TEMPO oder deaktivieren Sie das Metronom durch Drücken der Taste METRO. Starten Sie anschließend die Aufnahme durch Drücken der Taste START/STOP, oder alternativ direkt durch Ihr Spiel auf der Klaviatur. Während der Aufnahme leuchtet die Anzeige „Rec“ im Display permanent. Beenden Sie die Aufnahme durch Drücken der Taste START/STOP.

Nach abgeschlossener Aufnahme wechselt das Piano in den Song-Wiedergabe-Modus. Im Display erscheint „USER SONG“. Drücken Sie die Taste START/STOP um den Song wiederzugeben.

2. Kombinierte Aufnahme in den internen Speicher (MIDI)

Es ist möglich eine Kombination aus Ihrem Klavierspiel und einem auf dem Piano gespeicherten Song (außer dem User Song) aufzunehmen und als User Song zu speichern. Um eine kombinierte Aufnahme als MIDI-Datei im internen Speicher zu speichern, stellen Sie sicher, dass kein USB-Speichermedium im USB-Slot des Instrumentes steckt. Wählen Sie nun, wie im Kapitel Songwiedergabe beschrieben, einen Titel aus dem Songspeicher aus. Bei Bedarf können Sie die linke bzw. rechte Spur des Songs deaktivieren, um z.B. die rechte Hand eines Klavierstücks aufzunehmen und sich dabei von der linken Hand des Songspeichers begleiten zu lassen. Drücken Sie die Taste REC um das Instrument in Aufnahmebereitschaft zu versetzen. Befindet sich bereits eine Aufnahme im Speicher, erscheint die Meldung „Overwrite User Song?“ im Display. Folgen Sie den Anweisungen im Display, um die Aufnahme abzubrechen, oder den gespeicherten Song zum Überschreiben freizugeben. Die Aufnahmebereitschaft wird angezeigt, indem die „Rec“ Anzeige im Display blinkt und das Metronom startet (das Klicken des Metronoms dient lediglich zu Ihrer Orientierung, es wird nicht mit aufgezeichnet). Wählen Sie nun die gewünschte Song-Geschwindigkeit durch Drehen des Reglers TEMPO. Sollten Sie die Aufnahme ohne die Unterstützung des Metronoms tätigen wollen, können Sie das Metronom durch Drücken der Taste METRO deaktivieren. Starten Sie anschließend die Aufnahme durch Drücken der Taste START/STOP, oder alternativ direkt durch Ihr Spiel auf der Klaviatur. Während der Aufnahme leuchtet die Anzeige „Rec“ im Display permanent. Beenden Sie die Aufnahme durch Drücken der Taste START/STOP.

Nach abgeschlossener Aufnahme wechselt das Piano in den Song-Wiedergabe-Modus. Im Display erscheint „USER SONG“. Drücken Sie die Taste START/STOP um den Song wiederzugeben.

3. Aufnahme auf einem externen Speichermedium (mp3)

Das Piano kann Audiodaten im mp3-Format aufnehmen, sofern ein USB-Stick (2GB-128GB formatiert im Format FAT32) am USB-to-Device-Port des Instruments steckt. Drücken Sie die Taste REC um das Instrument in Aufnahmebereitschaft zu versetzen. Sollte der USB-Stick nicht im FAT32 Format formatiert sein, ist keine Aufnahme möglich. Im Display erscheint die Meldung „Unsupported USB format, Format USB flash drive?“. Folgen Sie in diesem Fall den Anweisungen im Display, oder entfernen Sie den USB-Stick aus der Buchse. Die Aufnahmebereitschaft wird angezeigt, indem die „Rec“ Anzeige im Display blinkt und das Metronom startet (das Klicken des Metronoms dient lediglich zu Ihrer Orientierung, es wird nicht mit aufgezeichnet). Wählen Sie nun die gewünschte Song-Geschwindigkeit durch Drehen des Reglers TEMPO. Sollten Sie die Aufnahme ohne die Unterstützung des Metronoms tätigen wollen, können Sie das Metronom durch Drücken der Taste METRO deaktivieren. Starten Sie anschließend die Aufnahme durch Drücken der Taste START/STOP, oder alternativ direkt durch Ihr Spiel auf der Klaviatur. Während der Aufnahme leuchtet die Anzeige „Rec“ im Display permanent. Beenden Sie die Aufnahme durch Drücken der Taste START/STOP. Nach abgeschlossener Aufnahme wechselt das Piano in den USB-Song-Wiedergabe-Modus. Im Display erscheint „SONG x“. Drücken Sie die Taste START/STOP um den Song wiederzugeben.

Bei dieser Art der Aufnahme kann zusätzlich zum Spiel auf der Klaviatur auch das Signal der AUX/MIC-Buchse mit aufgezeichnet werden.

Song-Wiedergabe (SONG, LEFT, RIGHT, START/STOP)

Drücken Sie die Taste SONG, um zur Songauswahl zu gelangen. Den gewünschten Song wählen Sie mit Hilfe des Drehrads rechts vom Display.

Drücken Sie Start/Stop um die Wiedergabe des gewählten Songs zu starten bzw. zu stoppen.

Die Geschwindigkeitseinstellung des Songs erfolgt über den Drehregler TEMPO (siehe Geschwindigkeit (TEMPO))


Mit den Tasten LEFT und RIGHT können Sie die linke bzw. rechte Spur (linke/rechte Hand) des Songs unabhängig ein- bzw. ausschalten. Ist eine der beiden Spuren deaktiviert, wird dies im Display durch „L-OFF“ bzw. „R-OFF“ angezeigt.

USB-Speicher (USB, START/STOP)

Um Songs vom USB-Speicher wiederzugeben, drücken Sie die Taste USB. Anschließend wählen Sie mit dem Drehrad rechts vom Display den gewünschten Song aus und starten diesen mit der Taste START/STOP. Drücken Sie diese Taste erneut, um die Songwiedergabe zu beenden.

Sollte der USB-Stick nicht richtig erkannt werden und/oder keine Songs angezeigt werden, vergewissern Sie sich, ob Daten im mp3 oder MIDI-Format im Rootverzeichnis des Sticks vorhanden sind und ob der Stick die richtige Größe und Formatierung aufweist (2-128MB, FAT32). Die Formatierung des Sticks im richtigen FAT32-Format kann direkt im Piano erfolgen. Drücken Sie hierzu die Taste REC. Ist der Stick in einem anderen Format als FAT32 formatiert erscheint im Display die Meldung: „Unsupported USB format, Format USB flash drive?“. Folgen Sie in diesem Fall den Anweisungen im Display. Achtung: beim Formatieren gehen alle auf dem Stick gespeicherten Daten verloren.

Bedieneinheit für Voice-Auswahl und weitere Funktionen



Auswahl der Klangfarbe (VOICE)

Mit dem VOICE-Button gelangen Sie in das Menü zur Auswahl der Klangfarbe. Nach Drücken der Taste VOICE erscheint im Display die Bezeichnung und Nummer der aktuell gewählten Klangfarbe. Drehen Sie nun am Drehregler rechts neben dem Display, um zu einer anderen Klangfarbe zu wechseln.

Im Modus Dual und Lower wechseln Sie durch mehrmaliges Drücken der Taste Voice zur Auswahl der jeweiligen Klangfarbe (R1, R2, L).

Demo der jeweiligen Klangfarbe (VOICE DEMO)

Durch Drücken der Taste VOICE DEMO können Sie zur jeweils aktuell gewählten Klangfarbe ein DEMO wiedergeben.

Kombination zweier Klangfarben (DUAL)

Um zwei Klangfarben gleichzeitig wiederzugeben, drücken Sie die Taste DUAL. Beim Spiel auf der Klaviatur erklingen nun zwei Klangfarben gleichzeitig. Diese Klangfarben werden als R1 (Main Voice) und R2 (Layer Voice) bezeichnet. Durch mehrmaliges Drücken der Taste VOICE können Sie die beiden Klangfarben getrennt wählen und gegebenenfalls mit dem Drehrad rechts vom Display ändern. Im Display wird R1 bzw. R2 angezeigt.

Die Lautstärken der Klangfarben können im Funktionsmenü anteilig eingestellt werden. Siehe: Funktionsmenü (FUNCTION)

Drücken Sie die Taste DUAL erneut, um diese Funktion zu beenden.

Kombination zweier Klangfarben (SPLIT)

Um die linke und die rechte Seite der Klaviatur mit unterschiedlichen Klangfarben zu belegen, drücken Sie die Taste SPLIT. Beim Spiel auf der Klaviatur erklingt nun auf der linken Seite der Tastatur eine andere Klangfarbe als auf der rechten Seite. Diese Klangfarben werden als L (Lower Voice) und R1 (Main Voice) bezeichnet. Durch mehrmaliges Drücken der Taste VOICE können Sie die beiden Klangfarben getrennt wählen und gegebenenfalls mit dem Drehrad rechts vom Display ändern. Im Display wird L bzw. R1 angezeigt.

Die Lautstärken der Klangfarben können im Funktionsmenü anteilig eingestellt werden. Siehe: Funktionsmenü (FUNCTION)

Die Position auf der Tastatur, an welcher die Lower Voice und die Main Voice aufeinandertreffen wird als Split-Punkt bezeichnet (Standard F#3). Halten Sie die Taste SPLIT gedrückt und drehen Sie am Drehrad rechts vom Display, um den Split-Punkt zu verschieben, oder drücken Sie bei gehaltener SPLIT-Taste direkt eine beliebige Taste der Klaviatur, um den Split-Punkt an diese Stelle zu setzen.

Drücken Sie die Taste SPLIT erneut, um diese Funktion zu beenden.

Split und Dual Funktion können kombiniert werden.

Teilen der Klaviatur (TWINOVA)

Drücken Sie die Taste TWINOVA, um die Twinova Funktion zu aktivieren. Diese Funktion teilt die Klaviatur des Pianos in zwei gleichberechtigte Hälften. Nun können zwei Klavierspieler (z.B. Lehrer und Schüler) das Instrument gleichzeitig nutzen. Die Trennung erfolgt bei einmaligem Drücken der TWINOVA-Taste ab der Taste F#4 (Mitte der Tastatur). Drücken Sie die Taste TWINOVA erneut, wird die Trennung zur Taste E3 (Trennung 1/3-2/3) verschoben.

In diesem Modus sind nicht mehr alle Pedal-Funktionen verfügbar. Die drei Pedale des Pianos funktionieren im TWINOVA-Modus alle als Sustain-Pedal, wobei das linke Pedal ausschließlich auf die linke Klaviaturhälfte und das rechte Pedal auf die rechte Klaviaturhälfte angewandt wird. Das mittlere Pedal hat ebenfalls die Funktion Sustain, wirkt jedoch auf beide Klaviaturhälften.

Funktionen wie DUAL und SPLIT sind im TWINOVA-Modus nicht verfügbar.

Um den TWINOVA-Modus zu verlassen, drücken Sie die Taste VOICE.

Piano-Modus (PIANO)

Drücken Sie die Taste PIANO, um in den Piano-Modus zu wechseln. Alle Parameter-Einstellungen des Instrumentes sind in diesem Modus für das Piano-Spiel optimiert.

Die Funktionen DUAL, SPLIT u.a. sind in diesem Modus nicht verfügbar.

Um den Piano-Modus zu verlassen, drücken Sie die Taste VOICE.

Funktionsmenü (FUNKTION)

1. Allgemeine Einstellungen

Drücken Sie die Taste FUNCTION, um ins Funktionsmenü zu gelangen.

Durch mehrmaliges Drücken der FUNCTION Taste, können Sie durch die einzelnen Funktionen blättern.

Nun können Sie durch Drehen des Drehrads rechts neben dem Display die Einstellung der jeweils angewählten Funktion ändern.

Die allgemeinen Einstellungen umfassen folgende Funktionen:

Transponieren (TRANSPOSE)

Mit dieser Funktion können Sie die Tonhöhe des Instruments in Halbtonschritten nach unten oder oben verschieben. Dies kann das Spielen schwieriger Stücke und das Zusammenspiel mit anderen Instrumenten erleichtern.

Oktavieren (OCTAVE R1, OCTAVE R2, OCTAVE L)

Mit dieser Funktion können Sie die Töne einer Voice (R1, R2, L) eine Oktave nach unten oder oben verschieben. Diese Funktion ist z.B. bei der Kombination mehrerer Voices (DUAL/SPLIT) interessant.

Anschlagsempfindlichkeit (TOUCH)

Mit dieser Funktion können Sie die Anschlagsempfindlichkeit der Tastatur verändern. Durch eine härtere Anschlagsempfindlichkeit kann ein versierter Spieler die Dynamikbandbreite des

Instrumentes in feineren Nuancen nutzen. Wollen Sie mit wenig Kraftaufwand bereits die volle Lautstärke des Instruments erreichen, wählen Sie eine weichere Einstellung. Die Anschlagsempfindlichkeit kann mit der Einstellung „Flat“ komplett deaktiviert werden. Nun erklingt jeder Tastenanschlag in der gleichen Lautstärke.

Lautstärkeanteile (VOLUME R1, VOLUME R2, VOLUME L, VOLUME MUSIC)

Mit dieser Funktion können Sie die Lautstärkeanteile der unterschiedlichen Voices (R1, R2, L), bzw. der Musikwiedergabe regeln. Diese Funktion kann bei der Kombination mehrerer Voices (DUAL/SPLIT), bzw. dem Zusammenspiel mit einem Song des Audioplayers hilfreich sein.

Taktart des Metronoms (METRONOME)

Mit dieser Funktion können Sie die Taktart des Metronoms und somit die besondere Betonung der „Eins“ wählen.

Lautsprecher EQ-Settings (SPEAKER EQ)

Mit dieser Funktion ändern Sie das Klangbild des gesamten Lautsprechersystems. Somit können Sie den Grundklang des Instrumentes Ihren Vorlieben, bzw. dem Musikstil bzw. den Raumgegebenheiten anpassen.

Saitenresonanz (STRING RES.)

Mit dieser Funktion können Sie die Stärke der Saitenresonanzsimulation einstellen. Beim natürlichen Klavier können auch Saiten mitschwingen, welche nicht vom Spieler angeschlagen wurden (Resonanzeffekt). Diese natürlichen Resonanzen werden in der Saitenresonanzsimulation elektronisch berechnet und verleihen Ihrem Instrument ein Obertonreicheres, natürlicheres Klangbild. Je nach Spielweise, gewählter Anschlagsempfindlichkeit und Musikstil kann ein zu hoher Anteil der Saitenresonanzsimulation störend erscheinen. Wählen Sie in diesem Falle einen niedrigeren Wert.

Effekte (REVERB TYPE, REVERB LEVEL, CHORUS TYPE, CHORUS LEVEL, MIC FX TYPE, MIC FX LEVEL)

Mit dieser Funktion können Sie den Pianoklang, bzw. das Mikrofon mit bestimmten Effekten belegen. Hier stehen Raumklangeffekte wie z.B. Hall, Soundeffekte wie z.B. Chorus und Mikrofoneffekte wie z.B. Echo zur Auswahl. Die Auswahl erfolgt jeweils zuerst bezüglich der Art und im nächsten Menüpunkt zur Lautstärke des Effekts.

Wiedergabemodus des Audio-Players (SONG LOOP)

Mit dieser Funktion können Sie den Wiedergabemodus des Audioplayers wählen. Durch die Aktivierung der Funktion „Song Loop“ wird entweder ein ausgewählter Song (Single), oder alle verfügbaren Songs (All) in einer Endlosschleife wiedergegeben.

Deaktivierung des internen Soundgenerators (LOCAL)

Mit der Local-Funktion können Sie den internen Soundgenerator deaktivieren (Local Off), falls Sie das Instrument als Steuerelement einer DAW, bzw. eines MIDI-fähigen Computerprogramms/App benutzen möchten.

Tabelle - allgemeine Einstellungen

Funktion	Display	Regelbereich
Transponieren	TRANPOSE	-12 - +12
Oktavieren der Voice R1	OCTAVE R1	-1 - +1
Oktavieren der Voice R1	OCTAVE R2	-1 - +1
Oktavieren der Voice L	OCTAVE L	-1 - +1
Anschlagsempfindlichkeit	TOUCH	Hard 2, Hard 1, Normal, Soft 1, Soft 2, Flat
Lautstärkeanteil Voice R1	VOLUME R1	0 - 32
Lautstärkeanteil Voice R2	VOLUME R2	0 - 32
Lautstärkeanteil Voice L	VOLUME L	0 - 32
Lautstärkeanteil Musicplayer	VOLUME MUSIC	0 - 32
Taktart des Metronoms	METRONOME	2/2, 0/4, 2/4, 3/4, 4/4,...9/4, 3/8, 6/8, 9/8, 12/8
Lautsprecher EQ-Einstellung	SPEAKER EQ	Piano, Classical, Jazz, Pop, Rock, R&B
Stärke der Saitenresonanz	STRING RES.	0 - 32
Raumklangeffekt	REVERB TYPE	Room 1-3, Hall 1-4, Church, My Garage, Piano Hall
Stärke des Raumklangeffekts	REVERB LEVEL	0 - 32
Voiceeffekt	CHORUS TYPE	Chorus 1-4, GM Cho. 1-2, Celeste 1-2, Symphonic 1-2, Delay 1-2
Stärke des Voiceeffekts	CHORUS LEVEL	0 - 32
Mikrofoneffekt	MIC FX TYPE	Echo, Pan, Stereo, Doubler, Distortion, Lo-Fi, Enhancer, Pitch Up, Pitch Down
Stärke des Mikrofoneffekts	MIC FX LEVEL	0 - 32
Wiedergabemodus	SONG LOOP	Single, All, Off
Deaktivierung des internen Soundgenerators (Local Off)	LOCAL	ON, OFF

Die jeweiligen Einstellungen werden beim Ausschalten des Instruments automatisch gesichert.

2. Weitere Einstellungen

Drücken und halten Sie die Taste FUNCTION, um ins Menü für weitere Einstellungen zu gelangen

Durch mehrmaliges Drücken der FUNCTION Taste, können Sie durch die einzelnen Funktionen blättern.

Nun können Sie durch Drehen des Drehrads rechts neben dem Display die Einstellung der jeweils angewählten Funktion ändern.

Die weiteren Einstellungen umfassen folgende Funktionen:

MIDI-Out Kanäle (MIDI OUT CH)

Mit dieser Funktion können Sie den MIDI-Ausgangskanal der Voice R1 ändern, falls es Ihre Anwendung erfordert.

Auto-Power-Off (POWER OFF)

Mit dieser Einstellung können Sie die Zeit bis zur automatischen Abschaltung des Instruments bei Nichtbenutzung einstellen. Um Energie zu sparen, sollte für die Auto-Off-Funktion immer der niedrigste mögliche Wert gewählt werden. Deaktivieren Sie die Auto-Off-Funktion ausschließlich für den Bühneneinsatz.

Zeit und Datumseinstellung (YEAR, MONTH, DAY, HOUR, MINUTE)

Hier können Sie die Systemzeit einstellen. Diese wird z.B. bei mp3 Musikaufnahmen vermerkt

Reset (SYSTEM RESET)

Mit dieser Funktion können Sie das Instrument auf Werkseinstellung zurücksetzen. Achtung: Das Zurücksetzen kann nicht rückgängig gemacht werden. Um das Piano auf Werkseinstellung zurückzusetzen, wählen Sie bei der Displayanzeige „Reset all setting?“ „YES“ (Drücken der Taste RIGHT). Andernfalls verlassen Sie den Menüpunkt durch die Auswahl „No“ (Drücken der Taste LEFT). Trennen Sie das Gerät beim Reset keinesfalls vom Strom, da es sonst zu irreparablen Schäden am Betriebssystem des Pianos kommen könnte.


Tabelle - weitere Einstellungen

Funktion	Display	Regelbereich
MIDI Kanaleinstellungen	MIDI OUT CH	1 - 16
Automatische Ausschaltung	POWER OFF	Never, 15min, 1hour
Systemzeit Jahr	YEAR	2015-2100
Systemzeit Monat	MONTH	Jan. – Dec.
Systemzeit Tag	DAY	1 - 31
Systemzeit Stunde	HOUR	0 - 23
Systemzeit Minute	MINUTE	0 - 59
Reset zur Werkseinstellung	SYSTEM RESET	No, Execute

Die jeweiligen Einstellungen werden beim Ausschalten des Instruments automatisch gesichert.

Anschluss eines Computers oder Smart-Geräts

Verbinden Sie den Computer, bzw. das Smart-Gerät mit dem passenden Kabel zur USB-to-Host-Buchse des Pianos. Schalten Sie anschließend das Piano ein.



Nutzen Sie hierfür die folgenden Kabel:

Verbindung zum PC: USB A zu B Kabel (ab Windows XP SP3/OSX 10.8)

Verbindung zum Smart-Gerät: USB C zu USB B Kabel (bedingt ab Android 4.0 – einige Android Geräte verfügen nicht über die erforderlichen Treiber. In diesem Fall ist keine Verbindung möglich, nutzen Sie nach Möglichkeit einen PC)

Verbindung zum Apple Smart-Gerät: Apple Camera Connection Kit (ab iOS 6.0)

Über den USB-to-Host Anschluss des Pianos können sowohl Audio, als auch MIDI-Daten kommuniziert werden.

Nutzen Sie das Piano als MIDI-Eingabegerät, kann bei Bedarf durch die Funktion LOCAL OFF im Funktionsmenü der interne Klanggenerator deaktiviert werden.

Trouble Shooting

Sollte eine Funktionsstörung auftreten, prüfen Sie bitte folgende Fehlerquellen.

Fehler	Ursache	Lösung
Das Piano lässt sich nicht einschalten	1. Das Netzkabel ist nicht eingesteckt 2. Die Steckdose hat keinen Strom	1. Stecken Sie das Netzkabel richtig ein 2. Nutzen Sie eine andere Steckdose
Das Piano gibt keinen Ton aus den Lautsprechern aus	1. Die Lautstärke ist auf den kleinsten Wert eingestellt 2. Ein Kopfhörer(adapter) steckt in der Kopfhörerbuchse 3. Das Netzkabel ist nicht eingesteckt	1. Erhöhen Sie die Lautstärkeeinstellung 2. Entfernen Sie den Kopfhörer(adapter) aus der Kopfhörerbuchse 3. Stecken Sie das Instrument an eine Steckdose an
Das Instrument gibt Störgeräusche aus	1. Es befinden sich Geräte mit Störeigenschaften (Gefrierschrank, Waschmaschine o.ä.) in der näheren Umgebung 2. Objekte auf oder in der Nähe des Instruments resonieren mit 3. Schraubverbindungen am Instrument haben sich durch die Vibrationen oder trockene Umgebungsluft gelockert 4. Die Störgeräusche treten nur bei Nutzung eines Kopfhörers auf	1. Entfernen Sie das Piano aus der näheren Umgebung von anderen Elektrogeräten (speziell solchen mit Motoren) 2. Entfernen Sie resonierende Objekte aus der Umgebung des Pianos 3. Ziehen Sie alle von außen erreichbaren Schrauben nach 4. Reinigen Sie den Kopfhörerstecker oder tauschen Sie den Kopfhörer aus

Produktspezifikationen

Keyboard	88 anschlagsdynamische Hammertasten mit Dreifachsensorik
Anschlagsempfindlichkeit	6 Stufen (Hard 2, Hard 1, Normal, Soft 1, Soft 2, Flat)
Max. Polyphonie	256
Voices	40
Demo	40
Pedale	3 (Soft, Sostenuto, Sustain)
Anschlüsse	USB to Host, USB to Device, 2x Kopfhörer, Aux-In/MIC-In, Aux Out
Lautsprecherleistung	2x30W + 2x20W
Abmessungen (BxTxH in mm)	1407x505x1062
Mitgeliefertes Zubehör	Netzteil 15V, 2500mA, + innen

WEEE-Erklärung (Waste of Electrical and Electronic Equipment)

Ihr Produkt wurde unter Verwendung hochwertiger Materialien und Komponenten entwickelt und hergestellt, die recycelbar und wiederverwendbar sind. Dieses Symbol bedeutet, dass elektrische und elektronische Geräte am Ende ihrer Lebensdauer vom Hausmüll getrennt entsorgt werden müssen.

Bitte entsorgen Sie dieses Gerät bei Ihrer örtlichen kommunalen Sammelstelle oder im Recycling-Center.

Bitte helfen Sie mit, die Umwelt zu schützen, in der wir alle leben.

Alle technischen Daten und Erscheinungsbilder können ohne vorherige Ankündigung geändert werden. Alle Angaben waren zum Zeitpunkt der Drucklegung korrekt. Die Musikhaus Kirstein GmbH übernimmt keine Gewähr für die Richtigkeit oder Vollständigkeit der in diesem Handbuch enthaltenen Beschreibungen, Fotos oder Aussagen. Gedruckte Farben und Spezifikationen können geringfügig vom Produkt abweichen. Produkte der Musikhaus Kirstein GmbH werden nur über autorisierte Händler vertrieben. Distributoren und Händler sind keine Vertreter der Musikhaus Kirstein GmbH und nicht befugt, die Musikhaus Kirstein GmbH in irgendeiner Weise, sei es ausdrücklich oder durch schlüssiges Handeln, rechtlich zu binden.



Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau – Germany

Telefon: 0049-8861-909494-0

Mail: info@kirstein.de



Appendix

Voice-Liste

No.	Voice Name	No.	Voice Name
1	Grand Piano	21	Cello
2	Grand Piano/Wide	22	Orchestral Harp
3	Bright Piano	23	String Ensembles 1
4	Electric Grand	24	String Ensembles 2
5	Honky Tonk	25	Choir Aahs
6	Harpsichord	26	Trumpet
7	E.Piano 1	27	Trombone
8	E.Piano 2	28	Tuba
9	Clavi	29	French Horn
10	Drawbar Organ	30	Soprano Sax
11	Percussive Organ	31	Alto Sax
12	Rock Organ	32	Tenor Sax
13	Church Organ	33	Baritone Sax
14	Reed Organ	34	Flute
15	Accordion	35	Pan Flute
16	Tango Accordion	36	Sitar
17	Guitar & Bass 1	37	Banjo
18	Guitar & Bass 2	38	Shamisen
19	Bass & Vibra	39	Koto
20	Violin	40	Bag Pipe

Song-Liste

No.	Song-Name	No.	Song-Name
1	The Entertainer	46	Four Little Swans
2	Rialto Ripples (Rag)	47	Progress
3	Neapolitan Song	48	Eclogue
4	Waltzes	49	The Limpid Stream
5	Turkish March	50	Brave Cavalier
6	Schos Doll's Dance No. 2	51	The Chatterbox
7	Minuet In D Major	52	Tarantella
8	Inquietude	53	Frankness
9	Italian Polka	54	Tender Grieving
10	Moment Musical	55	The Farewell
11	Prelude In C-Sharp Major	56	The Chase

12	The Happy Farmer	57	Habanera
13	The Rag-Time Dance	58	Prelude In C Major
14	Piano Sonata In C Major, K.330. III	59	Piano Sonata In C Major, K.545.
15	Mazurka	60	Piano Sonate op.49-2
16	Prelude In E Major	61	Serenade
17	Piano Sonata In A Major, K.331. I	62	Prelude D-Dur/D major BWV936
18	Waltz For Piano In G-Sharp Minor	63	Prelude C-Dur/C major BWV924
19	Gavotte	64	Toys Ragtime
20	L' Arabesque	65	Maple leaves Ragtime
21	Austria Variation	66	Chicken pecking Ragtime
22	Schoss Doll's Dance No. 7	67	Pretty girl Ragtime
23	To A Wild Rose	68	Menuett G dur 3
24	Gavotte I	69	Perpetuum mobile
25	Waltz	70	The Nightingale was singing
26	Minuet In G Major (BWV Anh. 116)	71	Gipsy Rondo
27	Innocence	72	Fountain
28	Tchaikovsky Waltz	73	Fur Elise
29	Salut d' Amour	74	Prelude F-Dur/F major BWV927
30	Barcarolle	75	Prelude d-Moll/D minor BWV935
31	Robot Doll	76	Prelude e-Moll/E minor BWV938
32	Consolation	77	Prelude G-Dur/G major BWV936
33	2-Part Invention #13 In A Minor.B.W. Iii	78	Dove
34	Minuet In G Major (BWV Anh. 114)	79	Knight
35	Barcarolle	80	Ave Maria
36	Norwegian Dance No.2	81	Prelude G-Dur/G major BWV902a
37	Moseta Dance	82	Menuett G dur 4
38	The Small Gathering	83	The two part inventions 1
39	The Return	84	The two part inventions 2
40	The Wagtail	85	Gavotte
41	Bulie Dance	86	The angels singing
42	Tender Blossom	87	Minuet
43	Grace	88	Lyrical Rondo
44	Cherish The Memories	89	Swallow
45	Chopsticks	90	Minute Waltz

Die Inhalte der Voice-Liste und Song-Liste sind ohne Gewähr. Die Musikhaus Kirstein GmbH behält sich vor einzelne Klangfarben und Musikstücke ohne Angabe von Gründen abzuändern oder ersatzlos zu streichen.

CLASSIC CANTABILE

UP-1 Digital Piano



User manual

Version: 07/2025

Thank you for choosing this product. To ensure that you are fully satisfied with this product, carefully read and understand this manual before using this instrument. Keep this manual in a safe place. The operating instructions must be passed on to all subsequent users.



Observe operating instructions!

⚠ WARNING

The WARNING signal word identifies hazards that, without precautions, could result in serious injury.

⚠ NOTE

The signal word NOTE indicates general precautions that should be observed when handling the product.

⚠ NOTE

Images and screen images in this manual may differ slightly from the actual product's appearance, as long as it does not adversely affect the technical characteristics and safety of the product.

⚠ NOTE

All personal phrasing in this manual should be considered gender neutral.

These operating instructions apply to responsible persons and users who have been supervised by a person responsible for their safety or instructed in the operation of the device and who have proven to be able to handle the device.

⚠ WARNING

**Children should be supervised to ensure that they do not use this device as a toy.
Never allow children to play unattended with the packaging material.**

⚠ WARNING

Danger of property damage! We are not liable for accidents that occur as a result of non-observance of the safety instructions or due to incorrect handling.

All information in this manual has been checked to the best of our knowledge and belief. However, neither author nor publisher can be held liable for any damage related to the use of this manual.

Other product, brand and company names mentioned herein may be the trademarks of their respective owners. Compliance with all applicable copyright laws is the responsibility of the user of this document.

 WARNING

Caution

Please observe the following basic information in order not to endanger yourself or others and to avoid damage to external devices.

 NOTE

Warning

Do not disassemble the instrument and do not modify it. This could result in electric shock. Entrust a specialist workshop with any necessary service and maintenance or contact your dealer.

If you notice that the power cord is showing signs of wear, the unit shows malfunctions, burns, smells or smokes, unplug the power cord immediately and have a technician repair it. Before you clean the instrument, you should disconnect it from the mains power.

Always place the instrument on a level, stable surface to ensure a secure footing.

Do not use the instrument in a damp or wet environment.

Do not place vessels that are filled with liquids on the instrument, such as vases, glasses or bottles.

Do not place small objects on it that could slip in, such as hairpins, sewing needles or coins.

Do not place burning candles on the instrument.

 NOTE

Precautions

To avoid damage to the instrument, do not place it in places with high temperatures or dust, do not place it next to an air conditioner and avoid direct sunlight.

Do not place the instrument near other electrical equipment to avoid interference.

Do not use force when handling the instrument or place heavy objects on it.

Disconnect the instrument from the power if you are not going to use it for a long time. To disconnect the device from the mains, pull the plug, not the cable. Please handle the power cable with care. It should not be near radiators, you should not place heavy objects on it and move it so that people can not step on it or fall over it.

Please note that continuous high volume can permanently damage your hearing. Adjust the volume carefully.

 WARNING

Power adapter

Please connect the supplied power adapter to a power outlet with the correct voltage. Do not connect it to mains voltages other than those for which the instrument is intended. Unplug the power cord if you are not going to use the product for a long time or if there is upcoming a thunderstorm.

© 2024


These operating instructions are protected by copyright. The reproduction of these operating instructions, even in part, is only permitted with the approval of Musikhaus Kirstein GmbH. The same applies to the reproduction or copying of images, even in modified form.

Contents


Assembly.....	6
Front connection panel	9
USB to Host	9
USB to Device.....	9
Phones.....	9
Mic In / AUX	10
AUX	10
Control elements	11
Power switch and knobs for volume, brilliance, and tempo.....	11
Power	11
Overall volume (MASTER).....	11
Microphone volume (MIC).....	11
Piano lid simulation (BRILLIANCE)	11
Speed (TEMPO)	12
Control unit for metronome, song playback, and recording function	12
Metronome (METRO)	12
Recording (REC, LEFT, RIGHT, START/STOP).....	12
1. Simple recording to the internal memory (MIDI)	12
2. Combined recording to internal memory (MIDI)	13
3. Recording to an external storage medium (mp3).....	13
Song playback (SONG, LEFT, RIGHT, START/STOP).....	13
USB memory (USB, START/STOP)	14
Control panel for voice selection and other functions	14
Selecting the tone color (VOICE)	14
Demo of the respective tone (VOICE DEMO)	14
Combining two tones (DUAL)	15
Combining two tones (SPLIT)	15

Splitting the keyboard (TWINOVA)	15
Piano mode (PIANO)	16
Function menu (FUNCTION)	16
1. General settings	16
Transpose (TRANSPOSE)	16
Octave (OCTAVE R1, OCTAVE R2, OCTAVE L)	16
Touch sensitivity (TOUCH)	16
Volume levels (VOLUME R1, VOLUME R2, VOLUME L, VOLUME MUSIC)	16
Metronome time signature (METRONOME)	16
Speaker EQ settings (SPEAKER EQ).....	16
String resonance (STRING RES.).....	17
Effects (REVERB TYPE, REVERB LEVEL, CHORUS TYPE, CHORUS LEVEL, MIC FX TYPE, MIC FX LEVEL)	17
Audio player playback mode (SONG LOOP)	17
Deactivating the internal sound generator (LOCAL).....	17
Table - general settings.....	17
2. Additional settings	18
MIDI Out Channels (MIDI OUT CH).....	18
Auto power off (POWER OFF).....	18
Time and date setting (YEAR, MONTH, DAY, HOUR, MINUTE)	18
Reset (SYSTEM RESET)	18
Table - Additional settings	19
Connecting a computer or smart device.....	19
Troubleshooting	20
Product specifications	21
Appendix	23
Voice list.....	23
Song list	23

Assembly




First attach the two side panels **A** to the pedal bar **B** using the long screws **E** and cover the screw openings with the plastic caps **F**.



Now attach the back panel **C** to the base frame and secure it to the side panels and the pedal bar using the short, pointed screws **G**.






Carefully place the play table **D** on the base. Ask someone to help you with this and be careful of your fingers. Secure the keyboard securely to the rear metal brackets using the two plastic head screws **H** and to the mounting strip on the base frame using the six short screws **K**. It may be helpful to first screw all screws in by hand and then tighten them once all screws are in position.




Now connect the pedal cable **J** to the socket on the underside of the piano and plug the power supply's barrel plug into the power supply socket on the back of the instrument.



If desired, attach the headphone holder **M** to the back of the connection box. The two holes for the mini screws supplied with the holder are easy to feel.


Now place the piano in its intended location.

Caution: Now turn the support screw **L** on the pedal unit all the way out until it touches the floor.



► It may be useful to keep the packaging materials in case the instrument needs to be transported to a distant location.

Front connection panel



USB to Host

You can connect your piano to a computer using a USB A-to-B cable via the USB to Host socket.

USB to Device




You can use a USB stick to record songs in mp3 format or to play songs in mp3 or MIDI format. USB storage devices from 2-128GB are supported. The USB stick must be formatted in FAT32. Access is via the root directory. Do not create any subfolders.



Phones


Both headphone jacks can be used simultaneously. When headphones are connected, the instrument's speakers are automatically muted. Caution: Ensure that the volume is set to an appropriate level. Excessive volume or prolonged use of headphones can cause hearing damage.



Mic In / AUX In

The **Mic In** input allows you to play a dynamic microphone through the speakers of your piano. To do this, set the **selector switch to the MIC position**. Caution: Depending on the quality of the microphone, feedback may occur. Avoid excessive volume and do not point the microphone towards the speakers of the piano.

The **AUX In** input allows you to play music from an external music source through your piano's speakers. To do this, set the **selector switch to the AUX IN position**.




AUX Out

You can use the AUX Out connection to connect your piano to a music amplifier.

Control elements

Power switch and knobs for volume, brilliance, and tempo



Power

The power switch turns your instrument on. Please turn off your instrument when not in use to save energy.

This instrument has an auto power off function. To save energy, the piano will turn itself off if it is not used for a long period of time.

Overall volume (MASTER)

This knob lets you adjust the volume of your piano. Always turn this knob to zero before using your instrument and before connecting peripheral devices (headphones, microphone, USB device/stick, external amplifier, external player, recording device), and then adjust the volume to the desired level.

Microphone volume (MIC)

This knob lets you adjust the volume of a connected microphone. Always turn this knob to zero before connecting a microphone, then adjust the volume to the desired level.

Piano lid simulation (BRILLIANCE)

This control simulates the opening and closing of the piano lid on a real concert grand piano. This knob lets you adjust the treble of the sound reproduction. Turn the knob to the left for a warmer sound and to the right for a cooler, more brilliant sound.


Speed (TEMPO)

Turn this knob to adjust the tempo.

Press the knob briefly to return to the original tempo.

Press and hold the knob to switch from the tempo display in BPM (30-280 beats per minute) to the classic tempo notation (Grave to Prestissimo) on the display. The tempo display then automatically returns to the standard display (BPM).

Control unit for metronome, song playback, and recording function



Metronome (METRO)

Press the METRO button to start the metronome. Press the METRO button again to stop the metronome.

The speed of the metronome is set using the TEMPO knob (see Speed (TEMPO)).

The time signature of the metronome can be changed in the function menu if necessary (see Function menu (FUNCTION)).

The metronome signal is not output via the AUX OUT and USB-to-Host jacks.

The metronome signal is not recorded in recording mode.

Recording (REC, LEFT, RIGHT, START/STOP)

1. Simple recording to the internal memory (MIDI)

The piano has an internal memory that can store one user song in MIDI format. To record a song as a MIDI file in the internal memory, make sure that no USB storage device is inserted in the instrument's USB slot. Press the REC button to put the instrument in recording mode. If there is already a recording in memory, the message "Overwrite User Song?" appears on the display. Follow the instructions on the display to cancel the recording or to release the saved song for overwriting. The instrument is ready to record when the "Rec" indicator flashes on the display and the metronome starts (the metronome click is for your reference only and is not recorded). Now select

the desired metronome speed by turning the TEMPO knob or deactivate the metronome by pressing the METRO button. Then start recording by pressing the START/STOP button or, alternatively, by playing directly on the keyboard. During recording, the "Rec" indicator on the display lights up continuously. Stop recording by pressing the START/STOP button.

Once the recording is complete, the piano switches to song playback mode. "USER SONG" appears on the display. Press the START/STOP button to play back the song.

2. Combined recording to internal memory (MIDI)

It is possible to record a combination of your piano playing and a song stored on the piano (except for the user song) and save it as a user song. To save a combined recording as a MIDI file in the internal memory, make sure that no USB storage device is inserted in the USB slot of the instrument. Now select a title from the song memory as described in the Song playback section. If necessary, you can deactivate the left or right track of the song, for example to record the right hand of a piano piece while being accompanied by the left hand from the song memory. Press the REC button to put the instrument in record mode. If there is already a recording in memory, the message "Overwrite User Song?" appears on the display. Follow the instructions on the display to cancel the recording or to enable the stored song to be overwritten. The instrument is ready to record when the "Rec" indicator flashes on the display and the metronome starts (the metronome click is for your reference only and is not recorded). Now select the desired song speed by turning the TEMPO knob. If you want to record without the metronome, you can turn it off by pressing the METRO button. Then start recording by pressing the START/STOP button or by playing the piano. While recording, the "Rec" indicator on the display will light up continuously. Stop recording by pressing the START/STOP button.

Once recording is complete, the piano switches to song playback mode. "USER SONG" appears on the display. Press the START/STOP button to play back the song.

3. Recording to an external storage medium (mp3)

The piano can record audio data in mp3 format if a USB stick (2GB-128GB formatted in FAT32 format) is inserted into the USB-to-Device port of the instrument. Press the REC button to put the instrument in recording mode. If the USB stick is not formatted in FAT32 format, recording is not possible. The message "Unsupported USB format, Format USB flash drive?" appears on the display. In this case, follow the instructions on the display or remove the USB stick from the socket. The recording is ready when the "Rec" indicator flashes on the display and the metronome starts (the clicking of the metronome is for your orientation only and is not recorded). Now select the desired song speed by turning the TEMPO knob. If you want to record without the metronome, you can deactivate it by pressing the METRO button. Then start recording by pressing the START/STOP button or, alternatively, by playing directly on the keyboard. During recording, the "Rec" indicator on the display lights up continuously. Stop recording by pressing the START/STOP button. Once recording is complete, the piano switches to USB song playback mode. "SONG x" appears on the display. Press the START/STOP button to play back the song.

With this type of recording, the signal from the AUX/MIC jack can also be recorded in addition to the performance on the keyboard.

Song playback (SONG, LEFT, RIGHT, START/STOP)

Press the SONG button to access the song selection screen. Select the desired song using the rotary knob to the right of the display.

Press Start/Stop to start or stop playback of the selected song.

The speed of the song can be adjusted using the TEMPO knob (see Speed (TEMPO)).


Use the LEFT and RIGHT buttons to switch the left and right tracks (left/right hand) of the song on or off independently. If one of the two tracks is deactivated, this is indicated on the display by "L-OFF" or "R-OFF."

USB memory (USB, START/STOP)

To play songs from USB storage, press the USB button. Then use the rotary knob to the right of the display to select the desired song and start it with the START/STOP button. Press this button again to stop song playback.

If the USB stick is not recognized correctly and/or no songs are displayed, make sure that there are files in mp3 or MIDI format in the root directory of the stick and that the stick has the correct size and formatting (2-128MB, FAT32). The stick can be formatted to the correct FAT32 format directly on the piano. To do this, press the REC button. If the stick is formatted in a format other than FAT32, the message "Unsupported USB format, Format USB flash drive?" appears on the display. In this case, follow the instructions on the display. Caution: formatting will delete all data stored on the stick.

Control panel for voice selection and other functions



Selecting the tone color (VOICE)

Press the VOICE button to access the menu for selecting the tone. After pressing the VOICE button, the name and number of the currently selected tone appear on the display. Now turn the rotary control to the right of the display to switch to a different tone.

In Dual and Lower mode, press the Voice button several times to select the respective tone (R1, R2, L).

Demo of the respective tone (VOICE DEMO)

Press the VOICE DEMO button to play a demo of the currently selected tone.

Combining two tones (DUAL)

To play two tones simultaneously, press the DUAL button. When you play the keyboard, two tones will sound simultaneously. These tones are referred to as R1 (main voice) and R2 (layer voice). By pressing the VOICE button several times, you can select the two tones separately and change them using the rotary knob to the right of the display. R1 or R2 is shown on the display.

The volumes of the tones can be adjusted proportionally in the function menu. See: Function menu (FUNCTION)

Press the DUAL button again to exit this function.

Combining two tones (SPLIT)

To assign different tones to the left and right sides of the keyboard, press the SPLIT button. When you play the keyboard, a different tone will sound on the left side of the keyboard than on the right side. These tones are referred to as L (lower voice) and R1 (main voice). By pressing the VOICE button several times, you can select the two tones separately and change them using the rotary knob to the right of the display. L or R1 is shown on the display.

The volumes of the tones can be adjusted proportionally in the function menu.
See: Function menu (FUNCTION)

The position on the keyboard where the lower voice and the main voice meet is called the split point (default F#3). Hold down the SPLIT button and turn the dial to the right of the display to move the split point, or press any key on the keyboard while holding down the SPLIT button to set the split point at that position.

Press the SPLIT button again to exit this function.

The split and dual functions can be combined.

Splitting the keyboard (TWINOVA)

Press the TWINOVA button to activate the Twinova function. This function divides the piano keyboard into two equal halves. Now two piano players (e.g., teacher and student) can use the instrument at the same time. Pressing the TWINOVA button once divides the keyboard at the F#4 key (center of the keyboard). Pressing the TWINOVA button again shifts the division to the E3 key (division 1/3-2/3).

In this mode, not all pedal functions are available. In TWINOVA mode, all three pedals of the piano function as sustain pedals, with the left pedal applied exclusively to the left half of the keyboard and the right pedal applied exclusively to the right half of the keyboard. The middle pedal also has a sustain function, but it affects both halves of the keyboard.

Functions such as DUAL and SPLIT are not available in TWINOVA mode.

To exit TWINOVA mode, press the VOICE button.

Piano mode (PIANO)

Press the PIANO button to switch to Piano mode. All parameter settings of the instrument are optimized for piano playing in this mode.

The DUAL, SPLIT, and other functions are not available in this mode.

To exit Piano mode, press the VOICE button.

Function menu (FUNCTION)

1. General settings

Press the FUNCTION button to access the function menu.

Press the FUNCTION button repeatedly to scroll through the individual functions.

You can now change the setting for the selected function by turning the rotary knob to the right of the display.

The general settings include the following functions:

Transpose (TRANPOSE)

This function allows you to shift the pitch of the instrument up or down in semitone steps. This can make it easier to play difficult pieces and to play together with other instruments.

Octave (OCTAVE R1, OCTAVE R2, OCTAVE L)

This function allows you to shift the notes of a voice (R1, R2, L) up or down by an octave. This function is useful, for example, when combining multiple voices (DUAL/SPLIT).

Touch sensitivity (TOUCH)

This function allows you to change the touch sensitivity of the keyboard. A harder touch sensitivity allows an experienced player to use the dynamic range of the instrument with finer nuances. If you want to achieve the full volume of the instrument with little effort, choose a softer setting. The touch sensitivity can be completely deactivated with the "Flat" setting. Now every key stroke sounds at the same volume.

Volume levels (VOLUME R1, VOLUME R2, VOLUME L, VOLUME MUSIC)

This function allows you to control the volume levels of the different voices (R1, R2, L) or music playback. This function can be useful when combining multiple voices (DUAL/SPLIT) or when playing along with a song from the audio player.

Metronome time signature (METRONOME)

This function allows you to select the time signature of the metronome and thus the particular emphasis on the "one."

Speaker EQ settings (SPEAKER EQ)

This function allows you to change the sound of the entire speaker system. This allows you to adjust the basic sound of the instrument to your preferences, the style of music, or the room acoustics.

String resonance (STRING RES.)

This function allows you to adjust the strength of the string resonance simulation. On a natural piano, strings that are not struck by the player can also resonate (resonance effect). These natural resonances are calculated electronically in the string resonance simulation and give your instrument a more overtone-rich, natural sound. Depending on your playing style, the selected touch sensitivity, and the style of music, too much string resonance simulation may be distracting. In this case, select a lower value.

Effects (REVERB TYPE, REVERB LEVEL, CHORUS TYPE, CHORUS LEVEL, MIC FX TYPE, MIC FX LEVEL)

This function allows you to apply specific effects to the piano sound or the microphone. You can choose from room effects such as reverb, sound effects such as chorus, and microphone effects such as echo. First select the type of effect, then select the volume of the effect in the next menu item.

Audio player playback mode (SONG LOOP)

This function allows you to select the playback mode of the audio player. Activating the "Song Loop" function plays either a selected song (Single) or all available songs (All) in an endless loop.

Deactivating the internal sound generator (LOCAL)

The Local function allows you to deactivate the internal sound generator (Local Off) if you want to use the instrument as a control element for a DAW or a MIDI-enabled computer program/app.

Table - general settings

Function	Display	Control range
Transpose	TRANPOSE	-12 - +12
Transpose the voice by an octave. R1	OCTAVE R1	-1 - +1
Transpose voice R1 by an octave	OCTAVE R2	-1 - +1
Octave voice L	OCTAVE L	-1 - +1
Touch sensitivity	TOUCH	Hard 2, Hard 1, Normal, Soft 1, Soft 2, Flat
Volume level Voice R1	VOLUME R1	0 - 32
Volume level Voice R2	VOLUME R2	0 - 32
Volume level Voice L	VOLUME L	0 - 32
Volume level for music player	VOLUME MUSIC	0 - 32
Metronome time signature	METRONOME	2/2, 0/4, 2/4, 3/4, 4/4,...9/4, 3/8, 6/8, 9/8, 12/8
Speaker EQ setting	SPEAKER EQ	Piano, Classical, Jazz, Pop, Rock, R&B
String resonance strength	STRING RES.	0 - 32

Spatial sound effect	REVERB TYPE	Room 1-3, Hall 1-4, Church, My Garage, Piano Hall
Strength of the room sound effect	REVERB LEVEL	0 - 32
Voice effect	CHORUS TYPE	Chorus 1-4, GM Cho. 1-2, Celeste 1-2, Symphonic 1-2, Delay 1-2
Strength of the voice effect	CHORUS LEVEL	0 - 32
Microphone effect	MIC FX TYPE	Echo, Pan, Stereo, Doubler, Distortion, Lo-Fi, Enhancer, Pitch Up, Pitch Down
Microphone effect strength	MIC FX LEVEL	0 - 32
Playback mode	SONG LOOP	Single, All, Off
Deactivation of the internal sound generator (Local Off)	LOCAL	ON, OFF

The respective settings are automatically saved when the instrument is switched off.

2. Additional settings

Press and hold the FUNCTION button to access the menu for additional settings.

Press the FUNCTION button repeatedly to scroll through the individual functions.

You can now change the setting for the selected function by turning the rotary knob to the right of the display.

The additional settings include the following functions:

MIDI Out Channels (MIDI OUT CH)

This function allows you to change the MIDI output channel of Voice R1 if required for your application.

Auto power off (POWER OFF)

This setting allows you to set the time until the instrument switches off automatically when not in use. To save energy, always select the lowest possible value for the auto-off function. Only deactivate the auto-off function for stage use.

Time and date setting (YEAR, MONTH, DAY, HOUR, MINUTE)

Here you can set the system time. This is noted, for example, during mp3 music recordings.

Reset (SYSTEM RESET)

This function allows you to reset the instrument to its factory settings. Caution: The reset cannot be undone. To reset the piano to its factory settings, select "YES" (press the RIGHT button) when "Reset all settings?" appears on the display. Otherwise, exit the menu item by selecting "No" (press the LEFT button). Do not disconnect the device from the power supply during the reset, as this could cause irreparable damage to the piano's operating system.


Table - Additional settings

Function	Display	Control range
MIDI channel settings	MIDI OUT CH	1 - 16
Automatic switch-off	POWER OFF	Never, 15 min, 1 hour
System time year	YEAR	2015-2100
System time month	MONTH	Jan. – Dec.
System time day	DAY	1 - 31
System time hour	HOUR	0 - 23
System time minute	MINUTE	0 - 59
Reset to factory settings	SYSTEM RESET	No, Execute

The respective settings are automatically saved when the instrument is switched off.

Connecting a computer or smart device

Connect the computer or smart device to the USB-to-Host socket on the piano using the appropriate cable. Then turn on the piano.



Use the following cables for this purpose:

Connection to PC: USB A to B cable (Windows XP SP3/OSX 10.8 or higher)

Connection to a smart device: USB C to USB B cable (conditional from Android 4.0 – some Android devices do not have the necessary drivers. In this case, no connection is possible; use a PC if possible)

Connection to Apple smart device: Apple Camera Connection Kit (iOS 6.0 or higher)

Both audio and MIDI data can be communicated via the piano's USB-to-Host connection.

If you are using the piano as a MIDI input device, the internal sound generator can be deactivated if necessary using the LOCAL OFF function in the function menu.

Troubleshooting

If a malfunction occurs, please check the following sources of error.

Error	Cause	Solution
The piano cannot be switched on	1. The power cord is not plugged in 2. The power outlet has no power	1. Plug the power cord in properly 2. Use a different power outlet
No sound is coming from the speakers	1. The volume is set to the lowest level 2. Headphones (adapter) are plugged into the headphone jack 3. The power cord is not plugged in	1. Increase the volume setting 2. Remove the headphones (adapter) from the headphone jack 3. Plug the instrument into a power outlet
The instrument is emitting noise	1. There are devices with interference properties (freezer, washing machine, etc.) in the immediate vicinity 2. Objects on or near the instrument are resonating 3. Screw connections on the instrument have loosened due to vibrations or dry ambient air 4. The noise only occurs when headphones are used	1. Move the piano away from other electrical appliances (especially those with motors) 2. Remove any resonating objects from the vicinity of the piano 3. Tighten all screws that are accessible from the outside 4. Clean the headphone plug or replace the headphones

Product specifications

Keyboard	88 touch-sensitive hammer keys with triple sensor technology
Touch sensitivity	6 levels (Hard 2, Hard 1, Normal, Soft 1, Soft 2, Flat)
Max. polyphony	256
Voices	40
Demo	40
Pedals	3 (soft, sostenuto, sustain)
Connections	USB to Host, USB to Device, 2x headphones, Aux-In/MIC-In, Aux Out
Speaker output	2x30W + 2x20W
Dimensions (WxDxH in mm)	1407x505x1062
Included	Power supply 15V, 2500mA, + inside

WEEE declaration (Waste of Electrical and Electronic Equipment)

Your product has been designed and manufactured using high-quality materials and components that are recyclable and reusable. This symbol indicates that electrical and electronic equipment must be disposed of separately from household waste at the end of its service life.

Please dispose of this device at your local municipal collection point or recycling center.

Please help protect the environment in which we all live.

All technical data and appearances are subject to change without prior notice. All information was correct at the time of printing. Musikhaus Kirstein GmbH accepts no liability for the accuracy or completeness of the descriptions, photos, or statements contained in this manual. Printed colors and specifications may vary slightly from the product. Products from Musikhaus Kirstein GmbH are only sold through authorized dealers. Distributors and dealers are not representatives of Musikhaus Kirstein GmbH and are not authorized to legally bind Musikhaus Kirstein GmbH in any way, either expressly or by conclusive action.



Musikhaus Kirstein GmbH

Bernbeurener Str. 11

86956 Schongau – Germany

Phone: 0049-8861-909494-0

Email: info@kirstein.de



Appendix

Voice list

No.	Voice Name	No.	Voice Name
1	Grand Piano	21	Cello
2	Grand Piano/Wide	22	Orchestral Harp
3	Bright Piano	23	String Ensembles 1
4	Electric Grand	24	String Ensembles 2
5	Honky Tonk	25	Choir Aahs
6	Harpsichord	26	Trumpet
7	E.Piano 1	27	Trombone
8	E.Piano 2	28	Tuba
9	Clavi	29	French Horn
10	Drawbar Organ	30	Soprano Sax
11	Percussive Organ	31	Alto Sax
12	Rock Organ	32	Tenor Sax
13	Church Organ	33	Baritone Sax
14	Reed Organ	34	Flute
15	Accordion	35	Pan Flute
16	Tango Accordion	36	Sitar
17	Guitar & Bass 1	37	Banjo
18	Guitar & Bass 2	38	Shamisen
19	Bass & Vibra	39	Koto
20	Violin	40	Bag Pipe

Song list

No.	Song-Name	No.	Song-Name
1	The Entertainer	46	Four Little Swans
2	Rialto Ripples (Rag)	47	Progress
3	Neapolitan Song	48	Eclogue
4	Waltzes	49	The Limpid Stream
5	Turkish March	50	Brave Cavalier
6	Schos Doll's Dance No. 2	51	The Chatterbox
7	Minuet In D Major	52	Tarantella
8	Inquietude	53	Frankness
9	Italian Polka	54	Tender Grieving
10	Moment Musical	55	The Farewell
11	Prelude In C-Sharp Major	56	The Chase
12	The Happy Farmer	57	Habanera

13	The Rag-Time Dance	58	Prelude In C Major
14	Piano Sonata In C Major, K.330. III	59	Piano Sonata In C Major, K.545.
15	Mazurka	60	Piano Sonate op.49-2
16	Prelude In E Major	61	Serenade
17	Piano Sonata In A Major, K.331. I	62	Prelude D-Dur/D major BWV936
18	Waltz For Piano In G-Sharp Minor	63	Prelude C-Dur/C major BWV924
19	Gavotte	64	Toys Ragtime
20	L' Arabesque	65	Maple leaves Ragtime
21	Austria Variation	66	Chicken pecking Ragtime
22	Schos Doll's Dance No. 7	67	Pretty girl Ragtime
23	To A Wild Rose	68	Menuett G dur 3
24	Gavotte I	69	Perpetuum mobile
25	Waltz	70	The Nightingale was singing
26	Minuet In G Major (BWV Anh. 116)	71	Gipsy Rondo
27	Innocence	72	Fountain
28	Tchaikovsky Waltz	73	Fur Elise
29	Salut d' Amour	74	Prelude F-Dur/F major BWV927
30	Barcarolle	75	Prelude d-Moll/D minor BWV935
31	Robot Doll	76	Prelude e-Moll/E minor BWV938
32	Consolation	77	Prelude G-Dur/G major BWV936
33	2-Part Invention #13 In A Minor.B.W. Iii	78	Dove
34	Minuet In G Major (BWV Anh. 114)	79	Knight
35	Barcarolle	80	Ave Maria
36	Norwegian Dance No.2	81	Prelude G-Dur/G major BWV902a
37	Moseta Dance	82	Menuett G dur 4
38	The Small Gathering	83	The two part inventions 1
39	The Return	84	The two part inventions 2
40	The Wagtail	85	Gavotte
41	Bulie Dance	86	The angels singing
42	Tender Blossom	87	Minuet
43	Grace	88	Lyrical Rondo
44	Cherish The Memories	89	Swallow
45	Chopsticks	90	Minute Waltz

The contents of the voice list and song list are not guaranteed. Musikhaus Kirstein GmbH reserves the right to change individual sounds and pieces of music without giving reasons or to delete them without replacement.