



WH700NB Pro

Wireless Over-Ear Headphones with Active Noise Cancellation
Model: ED700NB

— Manual — (BC)

EN 1. Power ON/OFF



Press and hold the power button to power on/off.

2. First pairing



1. Once powered on, the headphones will automatically enter Bluetooth pairing mode.
2. Select "EDIFIER WH700NB Pro" in your device settings to connect.

3. Pairing for new device



1. In ON state, press and hold the **⏻** button for about 3 seconds to enter Bluetooth pairing mode.
2. Select "EDIFIER WH700NB Pro" in your device settings to connect.
Note: To disconnect the headphones, you need to manually connect to the device and disconnect.

4. Multipoint connection



1. Pair device A with the headphones successfully.
2. Press and hold the **⏻** button for 3 seconds to re-enter Bluetooth pairing mode and then select "EDIFIER WH700NB Pro" in device B settings to connect.
3. Select "EDIFIER WH700NB Pro" again in device A settings to connect.
Note: To disconnect the headphones, you need to manually connect to the device and disconnect.

5. Controls

• Call

• Music

• Mode

NOTE:
1. X1 Press: 1/2 Double Press: 1/2 Press and hold:
2. Default and control: right: Voice Assistant / Ambient Sound / Active Controller ON
3. Headset: ON/Off Controller for headset microphone connection.

6. Reset



In ON state, press "V" and "⏻" buttons for 5s to finish reset, then headphones will automatically enter Bluetooth pairing mode if successful.

7. Charging



Input: 5V=1A
Connect the headphones to a power source via the USB-C cable for charging.

NOTE:
1. Do not use the USB-C port as a data port (data transfer) by other devices.
2. When the power is off, the USB-C port will not work. Please ensure the headphones are powered on.

8. Wired Listening



Connect to the headphones via the USB-C cable. Wired listening will automatically disable Bluetooth mode.