


Mono channels: Pronomic M-502 (1)
 Pronomic M-602 (1-2), Pronomic M-802 (1-4)



Stereo channels: Pronomic M-502 (2/3-4/5)
 Pronomic M-602 (3/4-5/6), Pronomic M-802 (5/6-7/8)

AUX RETURNS

AUX RETURN LEFT (MONO)

AUX RETURN RIGHT



Art. 00024058 Pronomic M-502

Art. 00024059 Pronomic M-602

Art. 00024060 Pronomic M-802